Original		Rechange	
ON AVR Power	AVR Power On		Power
OFF Power	AVR Power Off	SHIFT +	Shift + Power
Cable/Sat	Cable/Sat	SHIFT + HDMI - SAT 0	Shift + 0
Disc	Disc	SHIFT + DVD 2	Shift + 2
DVR	DVR	SHIFT + CD - STB 3	Shift + 3
Radio	Radio	SHIFT + TUNER 6	Shift + 6
TV	TV	SHIFT + TV 1	Shift + 1
USB	USB	SHIFT + USB 8	Shift + 8
Game	Game	SHIFT + VIDEO 4	Shift + 4
Media Server	Media Server	SHIFT + BLUETOOTH 9	Shift + 9
Network	Network	SHIFT + TAPE 5	Shift + 5
AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7
Audio Effects	Audio Effects	LANG I/II AUDIO	Audio / Lang I/II
Video Modes	Video Modes	FORMAT PICTURE	Picture / Format
Surround Modes	Surround Modes	SURROUND	Eject / Surround
1	1	TV 1	1
ABC 2	2	DVD 2	2

Original		Rechange	
DEF 3	3	CD - STB 3	3
GHI 4	4	VIDEO 4	4
JKL 5	5	TAPE 5	5
MNO 6	6	TUNER 6	6
PQRS 7	7	AUX - HDD 7	7
TUV 8	8	USB 8	8
WXYZ 9	9	BLUETOOTH 9	9
LAST	Last	RETURN BACK	Back / Return
>9 0	0	HDMI - SAT 0	0
BACK/ EXIT	Back/Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Up		Up
MENU	Menu	HOME MENU	Menu / Home
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
A	Red	NETFLIX SEARCH	Red / Netflix / Search

Original		Rechange		Original		Rechange	
B	Green	APP REPEAT	Green / APP / Repeat	SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
C	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
D	Blue	Prime Video RANDOM	Blue / Prime Video / Random				
VOL +	Vol +	VOL +	Vol +				
MUTE	Mute	DIMMER MUTE	Mute / Dimmer				
CH Page Up	CH/Page Up	CH PAGE +	CH+ / Page+				
VOL −	Vol -	VOL −	Vol -				
CH Page Down	CH/Page Down	CH PAGE −	CH- / Page-				
I<<	I<<	PRESET- I<<	I<< / Preset-				
Pause	Pause	STEP-FREEZE Pause	Pause / Step / Freeze				
>>I	>>I	PRESET+ >>I	>>I / Preset+				
<<	<<	TUNE- <<	<< / Tune-				
Play	Play	SLOW Play	Play / Slow				
>>	>>	TUNE+ >>	>> / Tune+				
Stop	Stop	HOLD Stop	Stop / Hold				
AVR	AVR	LIST SMART	Smart / List				
INFO	Info	ANGLE INFO	Info / Angle				

Original	Rechange	Original	Rechange
Disc Power On	Power	Left	Left
Disc Power Off	Shift + Power	OK	OK
Disc	Display / Media	Right	Right
1	1	Down	Down
2	2	Disc Menu	D.Menu / Top
3	3	Red	Red / Netflix / Search
4	4	Green	Green / APP / Repeat
5	5	Yellow	Yellow / YouTube / Repeat
6	6	Blue	Blue / Prime Video / Random
7	7	Vol +	Vol +
8	8	Mute	Mute / Dimmer
9	9	Vol -	Vol -
Last	Back / Return	I<<	I<< / Preset-
0	0	Pause	Pause / Step / Freeze
Back/Exit	Exit / Cancel / Clear	>>I	>>I / Preset+
Up	Up	<<	<< / Tune-
Menu	Menu / Home	Play	Play / Slow

Original		Rechange		Original	Rechange
	>>	TUNE+	>> / Tune+		
	Rec	REC MODE	Rec / Rec Mode		
	Stop	HOLD	Stop / Hold		

Original		Rechange	
ON Device	DVR Power On		Power
DVR	DVR	MEDIA DISPLAY	Display / Media
1	1	TV 1	1
ABC 2	2	DVD 2	2
DEF 3	3	CD - STB 3	3
GHI 4	4	VIDEO 4	4
JKL 5	5	TAPE 5	5
MNO 6	6	TUNER 6	6
PQRS 7	7	AUX - HDD 7	7
TUV 8	8	USB 8	8
WXYZ 9	9	BLUETOOTH 9	9
>9 0	0	HDMI - SAT 0	0
	Up		Up
MENU	Menu	HOME MENU	Menu / Home
	Left		Left
	Right		Right
	Down		Down

Original		Rechange	
+ VOL	Vol +	+ VOL	Vol +
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
CH Page ▲	CH/ Page Up	+ CH PAGE	CH+ / Page+
VOL –	Vol -	VOL –	Vol -
CH Page ▼	CH/ Page Down	CH PAGE –	CH- / Page-

Original		Rechange	
ON AVR Power	AVR Power On	Power	
OFF Power	AVR Power Off	SHIFT + Power	Shift + Power
Cable/Sat	Cable/SAT	SHIFT + HDMI - SAT 0	Shift + 0
Disc	Disc	SHIFT + DVD 2	Shift + 2
DVR	DVR	SHIFT + CD - STB 3	Shift + 3
Radio	Radio	SHIFT + TUNER 6	Shift + 6
TV	TV	SHIFT + TV 1	Shift + 1
USB	USB	SHIFT + USB 8	Shift + 8
Game	Game	SHIFT + VIDEO 4	Shift + 4
Media Server	Media Server	SHIFT + BLUETOOTH 9	Shift + 9
Network	Network	SHIFT + TAPE 5	Shift + 5
AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7
Audio Effects	Audio Effects	LANG I/II AUDIO	Audio / Lang I/II
Video Modes	Video Modes	FORMAT PICTURE	Picture / Format
Surround Modes	Surround Modes	SURROUND	Eject / Surround
1	1	TV 1	1
ABC 2	2	DVD 2	2

Original		Rechange	
DEF 3	3	CD - STB 3	3
GHI 4	4	VIDEO 4	4
JKL 5	5	TAPE 5	5
MNO 6	6	TUNER 6	6
PQRS 7	7	AUX - HDD 7	7
TUV 8	8	USB 8	8
WXYZ 9	9	BLUETOOTH 9	9
LAST	Last	RETURN BACK	Back / Return
>9 0	0	HDMI - SAT 0	0
BACK/ EXIT	Back/Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
▲	Up	▲	Up
MENU	Menu	HOME MENU	Menu / Home
◀	Left	◀	Left
OK	OK	OK	OK
▶	Right	▶	Right
▼	Down	▼	Down
A	Red	NETFLIX SEARCH	Red / Netflix / Search

Original	Rechange	Original	Rechange
Green	Green / APP / Repeat	Info	Info / Angle
Yellow	Yellow / YouTube / Repeat	Sleep	Sleep / Timer
Blue	Blue / Prime Video / Random		
Vol +	Vol +		
Mute	Mute / Dimmer		
CH/ Page Up	CH+ / Page+		
Vol -	Vol -		
CH/ Page Down	CH- / Page-		
I <<	I << / Preset-		
Pause	Pause / Step / Freeze		
>>I	>>I / Preset+		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
Rec	Rec / Rec Mode		
Stop	Stop / Hold		
AVR	Smart / List		