Original		Rechange	
	Power		Power
	HDMI Control	HOME SMART	Smart
	Rec	REC MODE	Rec
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
	I<<		I<<
	<<		<<
	>>		>>
	>>I		>>I
	Screen	PICTURE FORMAT	Format
	Lang	SOUND DUAL	Dual
	Subtitle	AD SUBT	Subt
	PIP / World	ECO 3D	3D
	Red / Zoom	A	Red
	Green / Repeat	B	Green
	Yellow / Root	C	Yellow

Original		Rechange	
	Blue / Title	D	Blue
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
	Text	REPEAT TEXT	Text
	Swap	FAV PRE-CH	Pre Ch
	Up		Up
	Right		Right
	Down		Down
	Left		Left

Original		Rechange	
OK	OK	OK	Ok
P/CH +	P/CH +	CH +	Ch +
P/CH -	P/CH -	CH -	Ch -
Mute	Mute	MUTE	Mute
Vol +	Vol +	VOL +	Vol +
Vol -	Vol -	VOL -	Vol -
Menu	Menu	TOP MENU MENU	Menu
Source	Source	TIMER AV	AV
Return	Return	RETURN BACK	Back
EPG	EPG	-/-- GUIDE	Guide
Info	Info	DISPLAY INFO	Info
Sleep	Sleep	PROG SLEEP	Sleep
FAV	FAV	SHIFT + FAV PRE-CH	Shift + Pre Ch
Angle / Media	Angle / Media	APP MEDIA	Media
Search Mode	Search Mode	SEARCH TV/R	TV/R
Display	Display	SHIFT + DISPLAY INFO	Shift + Info
Presets	Presets	DISC NAV LIST	List

Original	Rechange