| Original | Rechange |
|---|---|
| Standby | Power |
| Mute | Mute |
| P/N | Smart |
| Open/Close | Eject |
| << | << |
| >> | >> |
| Play/Pause | Play |
| Stop | Stop |
| I<< | I<< |
| >>I | >>I |
| Setup | Options |
| Source | AV |
| Info | Info |
| Return/Exit | Exit |
| CH+ | Ch + |
| CH- | Ch - |
| Up | Up |

| Original | Rechange |
|---|---|
| Down | Down |
| Right | Right |
| Left | Left |
| OK | Ok |
| Vol + | Vol + |
| Vol - | Vol - |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| 0 | 0 |
| Slow | Back |

| Original | | Rechange | | Original | Rechange |
|---|---|---|---|---|---|
| GOTO | Goto | APP MEDIA | Media | | |
| PROGRAM | Program | PROG SLEEP | Sleep | | |
| TITLE/TTX | Title/TTX | REPEAT TEXT | Text | | |
| AUDIO | Audio | SOUND DUAL | Dual | | |
| SUBTITLE | Subtitle | AD SUBT | Subt | | |
| REPEAT | Red/Repeat | A | Red | | |
| A-B | Green/A-B | B | Green | | |
| MENU | Yellow/Menu | C | Yellow | | |
| ANGLE | Blue/Angle | D | Blue | | |
| EPG | EPG | -/-- GUIDE | Guide | | |
| FAVORITE | Favorite | FAV PRE-CH | Pre Ch | | |
| TV/RADIO | Tv/Radio | SEARCH TV/R | TV/R | | |
| ZOOM | Zoom | SHIFT + ZOOM | Shift + Eject | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |