Original		Rechange	
INPUT TV	Input TV	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS
POWER	Power	POWER	Power
INPUT	Input	RDS AV INPUT	AV / Input / RDS
RATIO	Ratio	FORMAT PICTURE	Picture / Format
	Bright+	SHIFT + ▲	Shift + Up
	Bright-	SHIFT + ▼	Shift + Down
SIMPLINK	Simplink	MEDIA DISPLAY	Display / Media
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
TEXT	Text	GOTO TEXT	Text / Goto
I/II	I/II	LANG I/II AUDIO	Audio / Lang I/II
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
	Stop	HOLD	Stop / Hold
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze

Original		Rechange	
	Rec	REC MODE	Rec / Rec Mode
	I<<	PRESET-	I<< / Preset-
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	>>I	PRESET+	>>I / Preset+
LIST	List	LIST SMART	Smart / List
MENU	Menu	HOME MENU	Menu / Home
Q.VIEW	Q.View	TOP MENU D.MENU	D.Menu / Top
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
VOL	Vol +	VOL	Vol +
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
PR	PR+	CH PAGE	CH+ / Page+

Original		Rechange	
VOL –	Vol -	VOL –	Vol -
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PR –	PR-	CH PAGE –	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
TIME	Time	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
0	0	HDMI - SAT 0	0
HOLD	Hold	SHIFT + HOLD ■	Shift + Stop /
SIZE	Size	SIZE ZOOM	Zoom / Size
UPDATE	Update	OPT-TOOLS SETUP	Setup / OPT / Tools

Original		Rechange	
INDEX	Index	SURROUND ⏏	Eject / Surround
REVEAL	Reveal	TITLE SOUND	Sound / Title

Original		Rechange	
POWER	Power		Power
	Stop	HOLD	Stop / Hold
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	I<<	PRESET-	I<< / Preset-
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	>>I	PRESET+	>>I / Preset+
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3

Original		Rechange	
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0

Original		Rechange	
POWER	Power		Power
INPUT	Input	RDS AV INPUT	AV / Input / RDS
	Stop	HOLD	Stop / Hold
	Play	SLOW	Play / Slow
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Rec	REC MODE	Rec / Rec Mode
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
+ PR	PR+	+ CH PAGE	CH+ / Page+
PR -	PR-	CH PAGE -	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7

Original		Rechange	
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0