| Original | | Rechange | |
|---|---|---|---|
| STANDBY | Standby | | Power |
| MUTE | Mute | MUTE | Mute |
| PIN | P/N | HOME SMART | Smart |
| OPEN/CLOSE | Open/Close | ZOOM | Eject |
| << | << | << | << |
| >> | >> | >> | >> |
| Play/Pause | Play/Pause | PLAY MODE | Play |
| STOP | Stop | | Stop |
| I<< | I<< | I<< | I<< |
| >>I | >>I | >>I | >>I |
| SETUP | Setup | SETTINGS OPT | Options |
| SOURCE | Source | TIMER AV | AV |
| INFO | Info | DISPLAY INFO | Info |
| RETURN/EXIT | Return/Exit | CLEAR EXIT | Exit |
| CH+ | CH+ | + CH | Ch + |
| CH- | CH- | CH − | Ch - |
| CH+ | Up | | Up |

| Original | | Rechange | |
|---|---|---|---|
| CH- | Down | | Down |
| VOL + | Right | | Right |
| VOL - | Left | | Left |
| OK | OK | OK | Ok |
| VOL + | Vol + | + VOL | Vol + |
| VOL - | Vol - | VOL − | Vol - |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| SLOW | Slow | RETURN BACK | Back |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| GOTO Goto | APP MEDIA Media | | |
| PROGRAM Program | PROG SLEEP Sleep | | |
| TITLE/TTX Title/TTX | REPEAT TEXT Text | | |
| AUDIO Audio | SOUND DUAL Dual | | |
| SUBTITLE Subtitle | AD SUBT Subt | | |
| REPEAT Red/Repeat | A Red | | |
| A-B Green/A-B | B Green | | |
| MENU Yellow/Menu | C Yellow | | |
| ANGLE Blue/Angle | D Blue | | |
| EPG EPG | -/-- GUIDE Guide | | |
| FAVORITE Favorite | FAV PRE-CH Pre Ch | | |
| TV/RADIO Tv/Radio | SEARCH TV/R TV/R | | |
| ZOOM Zoom | SHIFT + ZOOM Shift + Eject | | |
| | | | |
| | | | |
| | | | |
| | | | |