Original		Rechange	
POWER	Power	POWER	Power
MUTE	Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
FAV	FAV	FAV PRE-CH	Pre Ch
SUB-T	SUB-T	AD SUBT	Subt
Option	Option	SETTINGS OPT	Options
Setup	Setup	TOP MENU MENU	Menu
Up	Up	Up	Up

Original		Rechange	
Right	Right	Right	Right
Down	Down	Down	Down
Left	Left	Left	Left
OK	OK	OK	Ok
EXIT	Exit	CLEAR EXIT	Exit
HOME	Home	HOME SMART	Smart
<<	<<	<<	<<
>>	>>	>>	>>
Play / Pause	Play / Pause	PLAY MODE	Play
Play / Pause	Play / Pause	II	Pause
Stop	Stop	Stop	Stop
TV System	TV System	APP MEDIA	Media
VOL +	Vol +	+ VOL	Vol +
VOL -	Vol -	VOL –	Vol -
Edit	Edit	E-MANUAL D.MENU	D. Menu
AUDIO	Audio	SOUND DUAL	Dual
INFO	Info	DISPLAY INFO	Info

Original	Rechange	Original	Rechange
I << / P +	Ch +		
I << / P +	I <<		
>>I / P -	Ch -		
>>I / P -	>>I		
Repeat	Text		
Got o	Gui de		
Zoom	Ej ect		