Mandis shop

MOVIE CUBE K230

Original		Rechange	
	Power		Power
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
SLIDE	Slide	LIST SMART	Smart / List
DEVICE	Device	RDS AV INPUT	AV / Input / RDS
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
SLOW	I>/Slow	SHIFT + SLOW	Shift + Play /
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
DVD	DVD	DVD 2	2
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
COPY/DIR	Copy/Dir	GOTO TEXT	Text / Goto
TV SYSTEM	TV System	TOP MENU D.MENU	D.Menu / Top
VOL+	Vol +	+ VOL	Vol +
	Up		Up
NEXT	Next	PRESET+	>>I / Preset+
	Left		Left

Original		Rechange	
ENTER	Enter	OK	OK
	Right		Right
VOL-	Vol -	VOL –	Vol -
	Down		Down
PREV	Prev	PRESET-	I<< / Preset-
MENU	Menu	HOME MENU	Menu / Home
A-B	A-B	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
PLAY/PAUSE	Play	SLOW	Play / Slow
PLAY/PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
FR	<<	TUNE-	<< / Tune-
FF	>>	TUNE+	>> / Tune+
STOP	Stop	HOLD	Stop / Hold
DISPLAY	Display	MEDIA DISPLAY	Display / Media
MOVIE	Movie	NETFLIX SEARCH	Red / Netflix / Search
MUSIC	Music	APP REPEAT	Green / APP / Repeat
PHOTO	Photo	YouTube REPEAT A-B	Yellow / YouTube / Repeat
FILE	File	Prime Video RANDOM	Blue / Prime Video / Random

https://al-remotecontrols.fr/Etre/1362-790-telecommande-remplacement-pour-Etre-MovieCube-K230.html