| Original | | Rechange | |
|---|---|---|---|
| | Power | | Power |
| | 1 | TV 1 | 1 |
| ABC | 2 | DVD 2 | 2 |
| DEF | 3 | CD - STB 3 | 3 |
| Audio PIP | PI P | ANGLE INFO | I nf o / Angl e |
| GHI | 4 | VIDEO 4 | 4 |
| JKL | 5 | TAPE 5 | 5 |
| MNO | 6 | TUNER 6 | 6 |
| | [ <>] | FORMAT PICTURE | Pi cture / Format |
| | >I | PRESET+ | >>I / Preset + |
| PQRS | 7 | AUX - HDD 7 | 7 |
| TUV | 8 | USB 8 | 8 |
| WXYZ | 9 | BLUETOOTH 9 | 9 |
| | ? | LIST SMART | Smart / Li st |
| | I < | PRESET- | I << / Pr eset - |
| | 0 | HDMI - SAT 0 | 0 |
| | Mut e | DIMMER MUTE | Mut e / Di mmer |

| Original | | Rechange | |
|---|---|---|---|
| OSD | i / OSD | MEDIA DISPLAY | Di spl ay / Medi a |
| Disc Menu | Z/ Di sc Menu | HOME MENU | Menu / Home |
| P+ | Up | | Up |
| P+ | P+ | CH PAGE + | CH+ / Page+ |
| | Left | | Left |
| | Vol - | VOL − | Vol - |
| OK | OK | OK | OK |
| | Ri ght | | Ri ght |
| | Vol + | VOL + | Vol + |
| TXT | TXT | GOTO TEXT | Text / Got o |
| TXT | << | TUNE- | << / Tune- |
| P- | Down | | Down |
| P- | P- | CH PAGE − | CH- / Page- |
| TV-G | TV- G | -/-- GUIDE EPG | Gui de / EPG / -/-- |
| TV-G | >> | TUNE+ | >> / Tune+ |
| | Red/ I mage/ I > | NETFLIX SEARCH | Red / Netf l ix / Sear ch |
| | Gr een/ Ti mer | APP REPEAT | Gr een / APP / Repeat |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Play | SLOW Play / Slow | | |
| Yellow/Pause | YouTube REPEAT A-B Yellow / YouTube / Repeat | | |
| Pause | STEP-FREEZE Pause / Step / Freeze | | |
| Blue/Sound | Prime Video RANDOM Blue / Prime Video / Random | | |
| Stop | HOLD Stop / Hold | | |
| Blue/Sound | TITLE SOUND Sound / Title | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Rechange | |
|---|---|---|---|
| | Power | | Power |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | Audio | | Audio / Lang I/II |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | [ <>] | | Zoom / Size |
| | >I | | >>I / Preset+ |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | ? | | Smart / List |
| | I< | | I<< / Preset- |
| | 0 | | 0 |
| | i / OSD | | Display / Media |

| Original | | Rechange | |
|---|---|---|---|
| | Disc Menu | | D. Menu / Top |
| | Disc Menu | | Menu / Home |
| | Up | | Up |
| | P+ | | CH+ / Page+ |
| | Left | | Left |
| | Vol - | | Vol - |
| | OK | | OK |
| | Right | | Right |
| | Vol + | | Vol + |
| | TXT | | Text / Goto |
| | << | | << / Tune- |
| | Down | | Down |
| | P- | | CH- / Page- |
| | TV-G | | Guide / EPG / -/-- |
| | >> | | >> / Tune+ |
| | Red/Picture | | Picture / Format |
| | Red/Picture | | Red / Netflix / Search |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Green / Timer | TIMER SLEEP — Sleep / Timer | | |
| Play | SLOW — Play / Slow | | |
| Green / Timer | APP REPEAT — Green / APP / Repeat | | |
| Yellow/Pause | YouTube REPEAT A-B — Yellow / YouTube / Repeat | | |
| Pause | STEP-FREEZE — Pause / Step / Freeze | | |
| Blue/Sound | TITLE SOUND — Sound / Title | | |
| Stop | HOLD — Stop / Hold | | |
| Blue/Sound | Prime Video RANDOM — Blue / Prime Video / Random | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Rechange | |
|---|---|---|---|
| | Power | | Power |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | Audio | | Audio / Lang I/II |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | [ <>] | | Zoom / Size |
| | >I | | >>I / Preset+ |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | ? | | Smart / List |
| | I< | | I<< / Preset- |
| | 0 | | 0 |
| | Mute | | Mute / Dimmer |

| Original | | Rechange | |
|---|---|---|---|
| | i / OSD | | Display / Media |
| | Z/ Disc Menu | | Menu / Home |
| | Up | | Up |
| | P+ | | CH+ / Page+ |
| | Left | | Left |
| | Vol - | | Vol - |
| | OK | | OK |
| | Right | | Right |
| | Vol + | | Vol + |
| | TXT | | Text / Goto |
| | << | | << / Tune- |
| | Down | | Down |
| | P- | | CH- / Page- |
| | TV-G | | Guide / EPG / -/-- |
| | >> | | >> / Tune+ |
| | Red/ Image/ I> | | Red / Netflix / Search |
| | Red/ Image/ I> | | Shift + Play / Slow |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Green/Timer | APP REPEAT — Green / APP / Repeat | | |
| Play | SLOW — Play / Slow | | |
| Green/Timer | TIMER SLEEP — Sleep / Timer | | |
| Pause | STEP-FREEZE — Pause / Step / Freeze | | |
| Yellow/Pause | YouTube REPEAT A-B — Yellow / YouTube / Repeat | | |
| Blue/Sound | Prime Video RANDOM — Blue / Prime Video / Random | | |
| Stop | HOLD — Stop / Hold | | |
| Blue/Sound | TITLE SOUND — Sound / Title | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Rechange | |
|---|---|---|---|
| | Power | | Power |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | PIP/Audio | | Audio / Lang I/II |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | [<>] | | Zoom / Size |
| | >I | | >>I / Preset+ |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | ? | | Smart / List |
| | I< | | I<< / Preset- |
| | 0 | | 0 |
| | i/OSD | | Display / Media |

| Original | | Rechange | |
|---|---|---|---|
| | Z/Disc Menu | | Menu / Home |
| | P+ | | CH+ / Page+ |
| | Up | | Up |
| | Left | | Left |
| | Vol - | | Vol - |
| | OK | | OK |
| | Right | | Right |
| | Vol + | | Vol + |
| | TXT | | Text / Goto |
| | << | | << / Tune- |
| | P- | | CH- / Page- |
| | Down | | Down |
| | TV-G | | Guide / EPG / -/-- |
| | >> | | >> / Tune+ |
| | Red/Image/I> | | Picture / Format |
| | Red/Image/I> | | Red / Netflix / Search |
| | Green/Timer | | Green / APP / Repeat |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Play | SLOW Play / Slow | | |
| Green/Timer | TIMER SLEEP Sleep / Timer | | |
| Yellow/Pause | YouTube REPEAT A-B Yellow / YouTube / Repeat | | |
| Pause | STEP-FREEZE Pause / Step / Freeze | | |
| Blue/Sound | Prime Video RANDOM Blue / Prime Video / Random | | |
| Stop | HOLD Stop / Hold | | |
| Blue/Sound | TITLE SOUND Sound / Title | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |