Original		Rechange	
	Power		Power
	Red/ Sound↑		Red / Netflix / Search
	Red/ Sound↑		Sound / Title
	Green/ Picture/ ↓		Green / APP / Repeat
	Green/ Picture/ ↓		Picture / Format
	Yellow/ Feature		Yellow / YouTube / Repeat
	Blue/ Install		Blue / Prime Video / Random
	[≡]		Text / Goto
	[≡0]		Play / Slow
	[≡+]		Stop / Hold
	[≡x] / [· ·]		Pause / Step / Freeze
	[/ ≡] / [*]		Rec / Rec Mode
	[+] ([≡♦] / Wide		Zoom / Size
	[≡?] / PC		Fav / Marker / PC
	[≡i] / Guide		Guide / EPG / -/--
	1		1
	2		2

Original		Rechange	
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	P<P		Display / Media
	0		0
	-/--		Shift + Guide / EPG / -/--
	Vol -		Vol -
	Vol +		Vol +
	Mute		Mute / Dimmer
	P-		CH- / Page-
	P+		CH+ / Page+
	[i] / Info		Info / Angle
	TV/ DTV		TV/ Radio / Program

Original	Rechange	Original	Rechange
AV	RDS AV INPUT — AV / Input / RDS		
I - II	LANG I/II AUDIO — Audio / Lang I/II		
PP	RETURN BACK — Back / Return		
Up	Up		
Left	Left		
SELECT OK — OK/Select	OK — OK		
Right	Right		
M	HOME MENU — Menu / Home		
Down	Down		