Original		Rechange	
ON/STANDBY	On / Standby		Power
DISPLAY	Display	DISPLAY INFO	Info
BD/DVD	Input BD/DVD	SHIFT + 1	Shift + 1
VCR/DVR	Input VCR/DVR	SHIFT + 2	Shift + 2
CBL/SAT	Input CBL/SAT	SHIFT + 3	Shift + 3
GAME	Input Game	SHIFT + 4	Shift + 4
AUX	Input AUX	SHIFT + 5	Shift + 5
TUNER	Input Tuner	SHIFT + 6	Shift + 6
TV/CD	Input TV/CD	SHIFT + 7	Shift + 7
PORT	Input Port	SHIFT + 8	Shift + 8
TONE	Tone	SHIFT + OK	Shift + Ok
+	Tone +	SHIFT + ▲	Shift + Up
−	Tone -	SHIFT + ▼	Shift + Down
TUN MODE	Tun Mode	HOME SMART	Smart
MUTING	Muting	MUTE	Mute
+ CH	CH +	+ CH	Ch +
CH −	CH -	CH −	Ch -

Original		Rechange	
VOL +	Vol +	+ VOL	Vol +
VOL −	Vol -	VOL −	Vol -
GUIDE/TOP MENU SP A/B	Guide / Top Menu	E-MANUAL D.MENU	D. Menu
GUIDE/TOP MENU SP A/B	Guide / Top Menu	SHIFT + TOP MENU MENU	Shift + Menu
GUIDE/TOP MENU SP A/B	Guide / Top Menu	-/-- GUIDE	Guide
PREV CH/MENU	Prev CH / Menu	TOP MENU MENU	Menu
PREV CH/MENU	Prev CH / Menu	FAV PRE-CH	Pre Ch
	Up	▲	Up
PLAYLIST /CATEGORY	Left / Playlist/Category	◀	Left
ENTER	Enter	OK	Ok
PLAYLIST /CATEGORY	Right / Playlist/Category	▶	Right
	Down	▼	Down
SETUP	Setup	SETTINGS OPT	Options
AUDIO	Audio	SOUND DUAL	Dual
RETURN	Return	RETURN BACK	Back
⏮	I <<	<<	I <<
⏭	>>I	>>	>>I

Original		Rechange	
	<<		<<
	Play	PLAY MODE	Play
	>>		>>
	Pause / Play Reverse		Pause
	Stop		Stop
MOVIE/TV SEARCH	Movie/TV / Searc	A	Red
MOVIE/TV SEARCH	Movie/TV / Searc	SEARCH TV/R	TV/R
MUSIC REPEAT	Music / Repeat	B	Green
MUSIC REPEAT	Music / Repeat	REPEAT TEXT	Text
GAME RANDOM	Game / Random	C	Yellow
STEREO PLAY MODE	Stereo / Play	D	Blue
STEREO PLAY MODE	Stereo / Play	SHIFT + PLAY MODE	Shift + Play
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5

Original		Rechange	
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
+10 D.TUN DIMMER	+10 / Dimmer	SHIFT + GUIDE	Shift + Guide
+10 D.TUN DIMMER	D.Tun Tuner	APP MEDIA	Media
CLR SLEEP	Clear / Sleep	CLEAR EXIT	Exit
CLR SLEEP	Clear / Sleep	PROG SLEEP	Sleep

Original	Rechange
On/Standby	Power
Input BD/DVD	Shift + 1
Input VCR/DVR	Shift + 2
Input CBL/SAT	Shift + 3
Input Game	Shift + 4
Input AUX	Shift + 5
Input Tuner	Shift + 6
Input TV/CD	Shift + 7
Input Port	Shift + 8
Tone	Shift + Ok
Tone +	Shift + Up
Tone -	Shift + Down
Tun Mode	Smart
Muting	Mute
Vol +	Vol +
Vol -	Vol -
On/Standby	Shift + Power

Original	Rechange
Display BD/DVD	Info
Guide / Top Menu BD/DVD	Shift + Menu
Guide / Top Menu BD/DVD	D. Menu
Guide / Top Menu BD/DVD	Guide
Prev CH / Menu BD/DVD	Menu
Prev CH / Menu BD/DVD	Pre Ch
Up BD/DVD	Up
Left / Playlist/Category	Left
Enter BD/DVD	Ok
Right / Playlist/Category	Right
Down BD/DVD	Down
Setup BD/DVD	Options
Audio BD/DVD	Dual
Return BD/DVD	Back
I<< BD/DVD	I<<
>>I BD/DVD	>>I
<< BD/DVD	<<

Original		Rechange	
	Play BD/DVD	PLAY MODE	Play
	>> BD/DVD		>>
	Pause BD/DVD		Pause
	Stop BD/DVD		Stop
MOVIE/TV SEARCH	Movie/TV / Search BD/DVD	A	Red
MOVIE/TV SEARCH	Movie/TV / Search BD/DVD	SEARCH TV/R	TV/R
MUSIC REPEAT	Music / Repeat BD/DVD	B	Green
MUSIC REPEAT	Music / Repeat BD/DVD	REPEAT TEXT	Text
GAME RANDOM	Game / Random BD/DVD	C	Yellow
STEREO PLAY MODE	Stereo / Play Mode BD/DVD	D	Blue
STEREO PLAY MODE	Stereo / Play Mode BD/DVD	SHIFT + PLAY MODE	Shift + Play
1	1 BD/DVD	1	1
2	2 BD/DVD	2	2
3	3 BD/DVD	3	3
4	4 BD/DVD	4	4
5	5 BD/DVD	5	5
6	6 BD/DVD	6	6

Original		Rechange	
7	7 BD/DVD	7	7
8	8 BD/DVD	8	8
9	9 BD/DVD	9	9
0	0 BD/DVD	0	0
+10 D.TUN DIMMER	+10 / Dimmer	SHIFT + GUIDE	Shift + Guide
CLR SLEEP	CLR / Sleep	CLEAR EXIT	Exit
CLR SLEEP	CLR / Sleep	PROG SLEEP	Sleep

Original		Rechange	
ON/STANDBY	On / Standby	Power	
BD/DVD	Input BD/DVD	SHIFT + 1	Shift + 1
VCR/DVR	Input VCR/DVR	SHIFT + 2	Shift + 2
CBL/SAT	Input CBL/SAT	SHIFT + 3	Shift + 3
GAME	Input Game	SHIFT + 4	Shift + 4
AUX	Input Aux	SHIFT + 5	Shift + 5
TUNER	Input Tuner	SHIFT + 6	Shift + 6
TV/CD	Input TV/CD	SHIFT + 7	Shift + 7
PORT	Input Port	SHIFT + 8	Shift + 8
TONE	Tone	SHIFT + OK	Shift + Ok
+	Tone +	SHIFT + ▲	Shift + Up
−	Tone -	SHIFT + ▼	Shift + Down
TUN MODE	Tun Mode	HOME SMART	Smart
MUTING	Muting	MUTE	Mute
VOL ▲	Vol +	+ VOL	Vol +
VOL ▼	Vol -	VOL −	Vol -
ON/STANDBY	On / Standby	SHIFT + ⏻	Shift + Power

Original		Rechange	
DISPLAY	Display TV/CD	DISPLAY INFO	Info
+ DISC ALBUM	Disc + / Album + TV/CD	+ CH	Ch +
DISC ALBUM −	Disc - / Album TV/CD	CH −	Ch -
	Up TV/CD	▲	Up
PLAYLIST /CATEGORY	Left / Playlist/Category	◀	Left
ENTER	Enter TV/CD	OK	Ok
PLAYLIST /CATEGORY	Right / Playlist/Category	▶	Right
	Down TV/CD	▼	Down
SETUP	Setup TV/CD	SETTINGS OPT	Options
AUDIO	Audio TV/CD	SOUND DUAL	Dual
RETURN	Return TV/CD	RETURN BACK	Back
⏮	I<< TV/CD	⏮	I<<
⏭	>>I TV/CD	⏭	>>I
◀◀	<< TV/CD	«	<<
▶▶	>> TV/CD	»	>>
▶	Play TV/CD	PLAY MODE ▶	Play
⏸	Pause TV/CD	⏸	Pause

Original		Rechange	
	Stop TV/CD		Stop
MOVIE/TV SEARCH	Movie/TV / Search TV/CD	A	Red
MOVIE/TV SEARCH	Movie/TV / Search TV/CD	SEARCH TV/R	TV/R
MUSIC REPEAT	Music / Repeat TV/CD	B	Green
MUSIC REPEAT	Music / Repeat TV/CD	REPEAT TEXT	Text
GAME RANDOM	Game / Random	C	Yellow
STEREO PLAY MODE	Stereo / Play Mode TV/CD	D	Blue
STEREO PLAY MODE	Stereo / Play Mode TV/CD	SHIFT + PLAY MODE	Shift + Play
1	1 TV/CD	1	1
2	2 TV/CD	2	2
3	3 TV/CD	3	3
4	4 TV/CD	4	4
5	5 TV/CD	5	5
6	6 TV/CD	6	6
7	7 TV/CD	7	7
8	8 TV/CD	8	8
9	9 TV/CD	9	9

Original		Rechange	
0	0 TV/CD	0	0
+10 D.TUN DIMMER	+10 / Dimmer	GUIDE	Guide
CLR SLEEP	CLR / Sleep TV/C	CLEAR EXIT	Exit
CLR SLEEP	CLR / Sleep TV/C	PROG SLEEP	Sleep

Original		Rechange	
ON/STANDBY	On / Standby		Power
BD/DVD	Input BD/DVD	SHIFT + 1	Shift + 1
VCR/DVR	Input VCR/DVR	SHIFT + 2	Shift + 2
CBL/SAT	Input CBL/SAT	SHIFT + 3	Shift + 3
GAME	Input Game	SHIFT + 4	Shift + 4
AUX	Input AUX	SHIFT + 5	Shift + 5
TUNER	Input Tuner	SHIFT + 6	Shift + 6
TV/CD	Input TV/CD	SHIFT + 7	Shift + 7
PORT	Input Port	SHIFT + 8	Shift + 8
TONE	Tone	SHIFT + OK	Shift + Ok
+	Tone +	SHIFT + ▲	Shift + Up
−	Tone -	SHIFT + ▼	Shift + Down
TUN MODE	Tun Mode	HOME SMART	Smart
MUTING	Muting	MUTE	Mute
VOL ▲	Vol +	+ VOL	Vol +
VOL ▼	Vol -	VOL −	Vol -
ON/STANDBY	On / Standby Por	SHIFT + ⏻	Shift + Power

Original		Rechange	
DISPLAY	Display Port	DISPLAY INFO	Info
+ CH	CH + Port	+ CH	Ch +
CH −	CH - Port	CH −	Ch -
	Up Port	▲	Up
PLAYLIST /CATEGORY	Left / Playlist/Categor	◀	Left
ENTER	Enter Port	OK	Ok
PLAYLIST /CATEGORY	Right / Playlist/Categor	▶	Right
	Down Port	▼	Down
SETUP	Setup Port	SETTINGS OPT	Options
RETURN	Return Port	RETURN BACK	Back
⏮	I<< Port	⏮	I<<
⏭	>>I Port	⏭	>>I
⏪	<< Port	⏪	<<
►	Play Port	PLAY MODE ►	Play
⏩	>> Port	⏩	>>
◄ ❚❚	Pause / Play Reverse Port	❚❚	Pause
■	Stop Port	■	Stop

Original		Rechange	
MOVIE/TV SEARCH	Movie/TV / Search Port	A	Red
MOVIE/TV SEARCH	Movie/TV / Search Port	SEARCH TV/R	TV/R
MUSIC REPEAT	Music / Repeat	B	Green
MUSIC REPEAT	Music / Repeat	REPEAT TEXT	Text
GAME RANDOM	Game / Random	C	Yellow
STEREO PLAY MODE	Stereo / Play Mode Port	D	Blue
STEREO PLAY MODE	Stereo / Play Mode Port	SHIFT + PLAY MODE ▶	Shift + Play
1	1 Port	1	1
2	2 Port	2	2
3	3 Port	3	3
4	4 Port	4	4
5	5 Port	5	5
6	6 Port	6	6
7	7 Port	7	7
8	8 Port	8	8
9	9 Port	9	9
0	0 Port	0	0

Original		Rechange	
+10 D.TUN DIMMER	+10 / Dimmer	GUIDE	Guide
CLR SLEEP	CLR / Sleep Port	CLEAR EXIT	Exit
CLR SLEEP	CLR / Sleep Port	PROG SLEEP	Sleep