Original		Rechange	
STANDBY/ON	Power Receiver		Power
1 VCR/DVR	1	TV 1	1
1 VCR/DVR	VCR / DVR	SHIFT + VIDEO 4	Shift + 4
2 CBL/SAT	2	DVD 2	2
2 CBL/SAT	CBL / SAT	SHIFT + HDMI - SAT 0	Shift + 0
3	3	CD - STB 3	3
4 AUX	4	VIDEO 4	4
4 AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7
5 MULTI CH	5	TAPE 5	5
5 MULTI CH	Multi CH	SHIFT + TV 1	Shift + 1
6 DVD	6	TUNER 6	6
6 DVD	DVD	SHIFT + DVD 2	Shift + 2
7 TAPE	7	AUX - HDD 7	7
7 TAPE	TAPE	SHIFT + TAPE 5	Shift + 5
8 TUNER	8	USB 8	8
8 TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
9 CD	9	BLUETOOTH 9	9

Original		Rechange	
9 CD	CD	SHIFT + CD - STB 3	Shift + 3
10 D.TUN	D.TUN	LIST SMART	Smart / List
0 DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
0 DIMMER	0	HDMI - SAT 0	0
CLR SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
CH DISC ALBUM	CH+	CH PAGE +	CH+ / Page+
VOL	Vol +	VOL +	Vol +
CH DISC ALBUM	CH-	CH PAGE -	CH- / Page-
VOL	Vol -	VOL -	Vol -
GUIDE TOP MENU SP A/B	SP A/B	ANGLE INFO	Info / Angle
	Up		Up
PREVIOU MENU MUTING	Muting	DIMMER MUTE	Mute / Dimmer
-PLAYLIST/CAT	Left		Left
ENTER	Enter	OK	OK
-PLAYLIST/CA	Right		Right
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down

Original		Rechange	
RETURN	Return	RETURN BACK	Back / Return
	Pause / Play Rev	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
STEREO	Stereo	LANG I/II AUDIO	Audio / Lang I/II
SURROUND	Surround	SURROUND	Eject / Surround
	< Listening Mode	SHIFT + PRESET-	Shift + I<< / Preset-
	Listening Mode >	SHIFT + PRESET+	Shift + >>I / Preset+
AUDIO TEST TONE	Test Tone	NETFLIX SEARCH	Red / Netflix / Search
SUBTITLE CH SEL	CH Sel	APP REPEAT	Green / APP / Repeat
RANDOM LEVEL-	Level -	YouTube REPEAT A-B	Yellow / YouTube / Repeat
REPEAT LEVEL+	Level +	Prime Video RANDOM	Blue / Prime Video / Random
DISPLAY	Display	MEDIA DISPLAY	Display / Media

Original		Rechange	
L NIGHT DVD	L. Night	HOME MENU	Menu / Home
CINE FLTR HDD	Cine FLTR	TOP MENU D.MENU	D.Menu / Top

Original		Rechange		Original		Rechange	
STANDBY/ON	Power		Power	◄PLAYLIST/CAT	Left / Playlist / Ca		Left
VCR/DVR	1	TV 1	1	ENTER	Enter	OK	OK
CBL/SAT	2	DVD 2	2	PLAYLIST/CA►	Right / Playlist / C		Right
	3	CD - STB 3	3	SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
AUX	4	VIDEO 4	4		Down		Down
MULTI CH	5	TAPE 5	5	RETURN	Return	RETURN BACK	Back / Return
DVD	6	TUNER 6	6		Pause	STEP-FREEZE	Pause / Step / Freeze
TAPE	7	AUX - HDD 7	7		Play	SLOW	Play / Slow
TUNER	8	USB 8	8		Stop	HOLD	Stop / Hold
CD	9	BLUETOOTH 9	9		<<	TUNE-	<< / Tune-
10	+10/ 10/ -/ --	-/-- GUIDE EPG	Guide / EPG / -/--		>>	TUNE+	>> / Tune+
DIMMER	0/ 11	HDMI - SAT 0	0		I <<	PRESET-	I << / Preset-
SLEEP	CLR/ 12/ Sleep	TIMER SLEEP	Sleep / Timer		>>I	PRESET+	>>I / Preset+
SLEEP	CLR/ 12/ Sleep	CLEAR EXIT CANCEL	Exit / Cancel / Clear	STEREO	Stereo	TITLE SOUND	Sound / Title
GUIDE TOP MENU SP A/B	Guide/ Top	TOP MENU D.MENU	D. Menu / Top	SURROUND	Surround	SURROUND	Eject / Surround
	Up		Up		< Listening Mode	SHIFT + PRESET-	Shift + I << / Preset-
PREVIOUS MENU MUTING	Previous Menu/ Muting	HOME MENU	Menu / Home		Listening Mode >	SHIFT + PRESET+	Shift + >>I / Preset+

Original		Rechange		Original	Rechange
AUDIO / TEST TONE	Audio	LANG I/II / AUDIO	Audio / Lang I/II		
SUBTITLE / CH SEL	Subtitle	EQ / SUBTITLE	Subtitle / EQ		
RANDOM / LEVEL-	Level - / Random	Prime Video / RANDOM	Blue / Prime Video / Random		
REPEAT / LEVEL+	Level + / Repeat	APP / REPEAT	Green / APP / Repeat		
DISPLAY	Display	MEDIA / DISPLAY	Display / Media		
PLAY MODE / VCR	Play Mode VCR	SHIFT + VIDEO 4	Shift + 4		
L NIGHT / DVD	Play Mode DVD	SHIFT + DVD 2	Shift + 2		
CINE FLTR / HDD	Play Mode HDD	SHIFT + AUX-HDD 7	Shift + 7		

Original		Rechange	
STANDBY/ON	Power		Power
VCR/DVR	1	TV 1	1
CBL/SAT	2	DVD 2	2
AUX	3	CD-STB 3	3
MULTI CH	4	VIDEO 4	4
DVD	5	TAPE 5	5
TAPE	6	TUNER 6	6
TUNER	7	AUX-HDD 7	7
CD	8	USB 8	8
10	9	BLUETOOTH 9	9
DIMMER	+10/10/-/--	-/-- GUIDE EPG	Guide / EPG / -/--
SLEEP	0	HDMI-SAT 0	0
SLEEP	CLR/12/Sleep	TIMER SLEEP	Sleep / Timer
SLEEP	CLR/12/Sleep	CLEAR EXIT CANCEL	Exit / Cancel / Clear
CH DISC ALBUM	Disc/Album	CH PAGE	CH+ / Page+
VOL	Vol +	VOL	Vol +
CH DISC ALBUM	Disc/Album CH-	CH PAGE	CH- / Page-

Original		Rechange	
VOL	Vol -	VOL	Vol -
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
STEREO	Stereo	LANG I/II AUDIO	Audio / Lang I/II
SURROUND	Surround	SURROUND	Eject / Surround
	< Listening Mode	SHIFT + PRESET-	Shift + I<< / Preset-
	Listening Mode >	SHIFT + PRESET+	Shift + >>I / Preset+
RANDOM LEVEL-	Level -/Random	Prime Video RANDOM	Blue / Prime Video / Random
REPEAT LEVEL+	Level +/Repeat	APP REPEAT	Green / APP / Repeat
DISPLAY	Display	MEDIA DISPLAY	Display / Media

Original		Rechange	
STANDBY/ON	Standby / On		Power
VCR/DVR	VCR/DVR	VIDEO 4	4
CBL/SAT	CBL/SAT	HDMI - SAT 0	0
AUX	AUX	AUX - HDD 7	7
MULTI CH	Multi CH	TV 1	1
DVD	DVD	DVD 2	2
TAPE	Tape	TAPE 5	5
TUNER	Tuner	TUNER 6	6
CD	CD	CD - STB 3	3
D.Tun	D.Tun	LIST SMART	Smart / List
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
CLR SLEEP	CLR / Sleep	TIMER SLEEP	Sleep / Timer
CLR SLEEP	CLR / Sleep	CLEAR EXIT CANCEL	Exit / Cancel / Clear
CH DISC ALBUM	CH Disc	CH PAGE +	CH+ / Page+
VOL	Vol +	VOL +	Vol +
CH DISC ALBUM	CH Disc Album	CH PAGE -	CH- / Page-
VOL	Vol -	VOL -	Vol -

Original		Rechange	
	Up		Up
PREVIOU MENU MUTING	Muting	DIMMER MUTE	Mute / Dimmer
PLAYLIST/CAT	Left/Playlist/Ca		Left
ENTER	Enter	OK	OK
PLAYLIST/CAT	Right/Playlist/C		Right
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
	Rev. Play	STEP - FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
STEREO	Stereo	LANG I/II AUDIO	Audio / Lang I/II
SURROUND	Surround	SURROUND	Eject / Surround
	< Listening Mode	PRESET-	I<< / Preset-
	Listening Mode >	PRESET+	>>I / Preset+

Original	Rechange	Original	Rechange
Test Tone	Red / Netflix / Search		
CH Sel	Green / APP / Repeat		
Level -	Yellow / YouTube / Repeat		
Level +	Blue / Prime Video / Random		
Display	Display / Media		
L.Night / Play Mode DVD	Menu / Home		
Cine FLTR / Play Mode HDD	D.Menu / Top		