Original	Rechange	Original	Rechange
Mute	Mute / Dimmer	Yellow / Play	Play / Slow
Power	Power	Yellow / Play	Yellow / YouTube / Repeat
1	1	Blue / >>	>> / Tune+
2	2	Blue / >>	Blue / Prime Video / Random
3	3	Up	Up
4	4	Left	Left
5	5	OK	OK
6	6	Right	Right
7	7	Down	Down
8	8	SFI	D. Menu / Top
9	9	Exit / Recall	Back / Return
✓	Guide / EPG / -/--	Exit / Recall	Exit / Cancel / Clear
0	0	Info	Info / Angle
Red / <<	Red / Netflix / Search	Prog +	CH+ / Page+
Red / <<	<< / Tune-	TV / Radio	TV/ Radio /
Green / Stop	Green / APP / Repeat	Vol +	Vol +
Green / Stop	Stop / Hold	Prog -	CH- / Page-

Original		Rechange		Original	Rechange
MENU	Menu	HOME MENU	Menu / Home		
−	Vol -	VOL −	Vol -		
TV/SAT	TV/SAT	LIST SMART	Smart / List		
TXT	TXT	GOTO TEXT	Text / Goto		
STOP	Stop	STEP-FREEZE II	Pause / Step / Freeze		
EXT	EXT	MEDIA DISPLAY	Display / Media		
SAT1	SAT1 + OK	SHIFT + 2	Shift + 2		
SAT2	SAT2 + OK	SHIFT + 3	Shift + 3		
TV	TV + OK	SHIFT + 1	Shift + 1		
	PIP	FORMAT PICTURE	Picture / Format		

Original	Rechange	Original	Rechange
Mute	Mute / Dimmer	Green / Stop	Stop / Hold
Power	Power	Yellow / Play	Play / Slow
1	1	Yellow / Play	Yellow / YouTube / Repeat
2	2	Blue / >>	>> / Tune+
3	3	Blue / >>	Blue / Prime Video / Random
4	4	Up	Up
5	5	Left	Left
6	6	OK	OK
7	7	Right	Right
8	8	Down	Down
9	9	SFI	D. Menu / Top
✓	Guide / EPG / -/--	Exit / Recall	Exit / Cancel / Clear
0	0	Exit / Recall	Back / Return
A/B	Shift + Yellow / YouTube /	Info	Info / Angle
Red / <<	<< / Tune-	Prog +	CH+ / Page+
Red / <<	Red / Netflix / Search	TV / Radio	TV/ Radio /
Green / Stop	Green / APP / Repeat	Vol +	Vol +

Original	Rechange	Original	Rechange
Prog -	CH- / Page-		
Menu	Menu / Home		
Vol -	Vol -		
TV/SAT	Smart / List		
TXT	Text / Goto		
Stop	Pause / Step / Freeze		
EXT	Display / Media		
SAT1 + OK	SHIFT + DVD 2 Shift + 2		
SAT2 + OK	SHIFT + CD-STB 3 Shift + 3		
TV + OK	SHIFT + TV 1 Shift + 1		

Original	Rechange	Original	Rechange
Mute	Mute / Dimmer	Green / Stop	Green / APP / Repeat
Power	Power	Yellow / Play	Play / Slow
1	1	Yellow / Play	Yellow / YouTube / Repeat
2	2	Blue / >>	>> / Tune+
3	3	Blue / >>	Blue / Prime Video / Random
4	4	Up	Up
5	5	Left	Left
6	6	OK	OK
7	7	Right	Right
8	8	Down	Down
9	9	SFI	D. Menu / Top
✓	Guide / EPG / -/--	Exit / Recall	Back / Return
0	0	Exit / Recall	Exit / Cancel / Clear
A/B	Shift + Yellow / YouTube /	Info	Info / Angle
Red / <<	Red / Netflix / Search	Prog +	CH+ / Page+
Red / <<	<< / Tune-	TV / Radio	TV/ Radio /
Green / Stop	Stop / Hold	Vol +	Vol +

Original	Rechange	Original	Rechange
Prog -	CH- / Page-		
Menu	Menu / Home		
Vol -	Vol -		
TV/SAT	Smart / List		
TXT	Text / Goto		
Stop	Pause / Step / Freeze		
EXT	Display / Media		
SAT1 + OK	+ Shift + 2		
SAT2 + OK	+ Shift + 3		
TV + OK	+ Shift + 1		