Original		Rechange	
	Power		Power
	Input TV		TV/Radio /
	Input Av		AV / Input / RDS
	Guide		Guide / EPG / -/--
	Up		Up
	Exit		Exit / Cancel / Clear
	Left		Left
	OK		OK
	Right		Right
	Menu		Menu / Home
	Down		Down
	Return		Back / Return
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	[+]/Aspect		Picture / Format

Original		Rechange	
	Link Vieta		Smart / List
	Option		Setup / OPT /
	Direct Tv Rec		Shift + Rec / Rec Mode
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
i	i		Info / Angle
0 VCR	0/VCR	0	0
0 VCR	0/VCR		Shift + 4
	Mute		Mute / Dimmer
	CH+		CH+ / Page+

Original		Rechange	
+	Vol +	VOL +	Vol +
v	CH-	CH PAGE –	CH- / Page-
–	Vol -	VOL –	Vol -
TEXT	[≡] / Text	GOTO TEXT	Text / Goto
STTL	[≡♦] / STTL	EQ SUBTITLE	Subtitle / EQ
INDEX	[≡i] / Index	MEDIA DISPLAY	Display / Media
HOLD	[≡+] / Hold	SHIFT + HOLD	Shift + Stop /
⏻	Power DVD	SHIFT + ⏻	Shift + Power
REC	Rec DVD	REC MODE	Rec / Rec Mode
PROGR v	Programme Down	SHIFT + CH PAGE –	Shift + CH- /
AMME ^	Programme Up	SHIFT + CH PAGE +	Shift + CH+ /
⏮ ◀◀	<<| << DVD	TUNE- ◀◀	<< / Tune-
⏮ ◀◀	<<| << DVD	PRESET- ⏮	| << / Preset-
⏭ ▶▶	>>| >> DVD	PRESET+ ⏭	>>| / Preset+
⏭ ▶▶	>>| >> DVD	TUNE+ ▶▶	>> / Tune+
■	Stop DVD	HOLD ■	Stop / Hold
II/I▶	Pause/Step DVD	STEP-FREEZE II	Pause / Step / Freeze

Original		Rechange	
▶	Play DVD	SLOW ▶	Play / Slow

Original	Rechange
Power DVD	Power
Rec DVD	Rec / Rec Mode
Programme Down	CH- / Page-
Programme Up	CH+ / Page+
I << DVD	I << / Preset-
I << DVD	<< / Tune-
>>I DVD	>>I / Preset+
>>I DVD	>> / Tune+
Stop DVD	Stop / Hold
Pause/Step DVD	Pause / Step / Freeze
Play DVD	Play / Slow

Original	Rechange

Original	Rechange	Original	Rechange
Power VCR	Power		
Rec VCR	Rec / Rec Mode		
Programme Down	CH- / Page-		
Programme Up	CH+ / Page+		
<<| << VCR	I << / Preset-		
<<| << VCR	<< / Tune-		
>>| >>I VCR	>> / Tune+		
>>| >>I VCR	>>I / Preset+		
Stop VCR	Stop / Hold		
Pause/Step VCR	Pause / Step / Freeze		
Play VCR	Play / Slow		