Original		Rechange	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
INPUT SELECT	Input Select	TIMER AV	AV
DELETE *	*/Delecte	FAV PRE-CH	Pre Ch
PAGE CH	CH/Page+	+ CH	Ch +
CH	CH/Page-	CH −	Ch -
FUNCTION MENU	Function Menu	TOP MENU MENU	Menu
DIRECT NAVIGATOR	Direct Navigator	HOME SMART	Smart

Original		Rechange	
GUIDE	Guide	-/-- GUIDE	Guide
STATUS i	i/Status	DISPLAY INFO	Info
EXIT	Exit	CLEAR EXIT	Exit
OPTION	Option	SETTINGS OPT	Options
RETURN	Return	RETURN BACK	Back
OK	OK	OK	Ok
▲	Up	▲	Up
▼	Down	▼	Down
▶ II▶	Right/II>	▶	Right
◀ ◀II	<II/Left	◀	Left
	Red	A	Red
CHAPTER	Green/Chapter	B	Green
MANUAL SKIP -10s	Yellow/Manual Skip -10s	C	Yellow
SKIP +60s	Blue/Manual Skip +60s	D	Blue
ShowView	ShowView	APP MEDIA	Media
REC	Rec	REC MODE	Rec
PAUSE II PAUSE LIVE TV	Pause/Pause Live	II	Pause

Tv

Original	Rechange
PLAY/x1.3 Play/x1.3	PLAY MODE Play
STOP Stop	Stop
SKIP << Skip	<<
SKIP Skip >>|	>>|
SLOW/S << Slow/Search	<<
SLOW/SEARCH Slow/Search >>	>>
DIRECT TV REC Direct Tv Rec	SEARCH TV/R TV/R
DRIVE SELECT Select Drive	REPEAT TEXT Text
PROG/CHECK Prog/Check	PROG SLEEP Sleep
EXT LINK Ext Link	ECO 3D 3D
REC MODE Rec Mode	SHIFT + REC MODE Shift + Rec
AUDIO Audio	SOUND DUAL Dual
STTL [≡◆]/STTL	AD SUBT Subt
DISPLAY Display	SHIFT + DISPLAY INFO Shift + Info
TIME SLIP Time Slip	E-MANUAL D.MENU D. Menu
TV Power TV	SHIFT + Power Shift + Power
AV AV Tv	SHIFT + TIMER AV Shift + AV

Original	Rechange
CH CH+ Tv	SHIFT + CH + Shift + Ch +
CH CH- Tv	SHIFT + CH − Shift + Ch -
VOL + Vol + Tv	VOL + Vol +
VOL − Vol - Tv	VOL − Vol -