Original		Rechange	
⏻	Power	⏻	Power
SLEEP - AUTO OFF	Sleep/Auto Off	TIMER SLEEP	Sleep / Timer
CLOCK/ TIMER	Clock/Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
PLAY/ REC	Timer Play/Rec	REC MODE	Rec / Rec Mode
PROGRAM - CLEAR	Program/Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
PROGRAM - CLEAR	Program/Clear	SHIFT + PROGRAM TV/ RADIO	Shift + TV/Radio / Program
1	1	TV 1	1
ABC 2	2	DVD 2	2
DEF 3	3	CD - STB 3	3
PLAY MODE	Play Mode	LIST SMART	Smart / List
GHI 4	4	VIDEO 4	4
JKL 5	5	TAPE 5	5
MNO 6	6	TUNER 6	6
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
PQRS 7	7	AUX - HDD 7	7
TUV 8	8	USB 8	8
WXYZ 9	9	BLUETOOTH 9	9

Original		Rechange	
DISPLAY	Display	MEDIA DISPLAY	Display / Media
DEL	Del	RETURN BACK	Back / Return
0	0	HDMI - SAT 0	0
SPACE !"# ≥10	>10/Space	-/-- GUIDE EPG	Guide / EPG / -/--
CD ▶/II	Play/Pause CD	SLOW ▶	Play / Slow
TUNER / BAND	Tuner/Band	SHIFT + TUNER 6	Shift + 6
TUNER / BAND	Tuner/Band	PROGRAM TV/ RADIO	TV/Radio /
TAPE ▶	Play Tape	STEP - FREEZE II	Pause / Step / Freeze
STOP ■	Stop	HOLD ■	Stop / Hold
VOL —	Vol -	VOL —	Vol -
+ VOL	Vol +	+ VOL	Vol +
ALBUM	← Album	◀	Left
ALBUM	Album →	▶	Right
CURSOR REW	REW / I<< / ← Cursor / Down	PRESET- ⏮	I<< / Preset-
CURSOR REW	REW / I<< / ← Cursor / Down	▼	Down
CURSOR REW	REW / I<< / ← Cursor / Down	TUNE- ◀◀	<< / Tune-
CURSOR FF	FF / >>I / Cursor → / Up	PRESET+ ⏭	>>I / Preset+

Original	Rechange	Original	Rechange
FF / >>I / Cursc → / Up	Up		
FF / >>I / Cursc → / Up	>> / Tune+		
Intro	Info / Angle		
Marker	Fav / Marker / PC		
Title Search	Red / Netflix / Search		
Enter	OK		
Muting	Mute / Dimmer		
Sound	Sound / Title		
Surround	Eject / Surround		
Dimmer	Shift + Mute / Dimmer		