Original	Rechange
Standby AV	Power
Info	Info / Angle
Direct Navigator	Smart / List
Menu	Menu / Home
EPG	Guide / EPG / -/--
Exit	Exit / Cancel / Clear
Edit	Fav / Marker / PC
<<	<< / Tune-
>>	>> / Tune+
Delete	Back / Return
Prog/Check	Setup / OPT /
Up	Up
Down	Down
Left	Left
Right	Right
OK	OK
Red	Red / Netflix / Search

Original	Rechange
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
Stop	Stop / Hold
Pause	Pause / Step / Freeze
Play	Play / Slow
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Live	Display / Media

Original		Rechange		Original	Rechange
TV/RADIO	Tv/ Radi o	PROGRAM TV/ RADIO	TV/ Radi o /		
REC	Rec	REC MODE	Rec / Rec Mode		
REC PAUSE	Rec Pause	SHIFT + STEP - FREEZE	Shi ft + Pause / Step /		
VIEWER	Vi ewer	SIZE ZOOM	Zoom / Si ze		
SKIP	Ski p	RDS AV INPUT	AV / I nput / RDS		
BOOK SET	Set Book Mark	EQ SUBTITLE	Subt i t l e / EQ		
MARK GO	Go Book Mark	SHIFT + PROGRAM TV/ RADIO	Shi ft + TV/ Radi o / Program		
VOLUME	Vol +	+ VOL	Vol +		
	Vol -	VOL −	Vol -		
TIMER REC	Ti mer Rec	TIMER SLEEP	Sl eep / Ti mer		
REPLAY	Repl ay	PRESET+	>>I / Pr eset +		
AUDIO	Audi o	LANG I/II AUDIO	Audi o / Lang I / I I		
ASPECT	Aspect	FORMAT PICTURE	Pi cture / For mat		

Original	Rechange	Original	Rechange
Power Tv	SHIFT + Power	Up	Up
Tv/AV Tv	SHIFT + RDS AV INPUT	Down	Down
CH+ TV	CH+ / Page+	Left	Left
CH- Tv	CH- / Page-	Right	Right
Vol + Tv	SHIFT + VOL +	OK	OK
Vol - Tv	SHIFT + VOL -	Red	NETFLIX SEARCH / Red / Netflix / Search
Standby AV	Power	Green	APP REPEAT / Green / APP / Repeat
Info	ANGLE INFO / Info / Angle	Yellow	YouTube REPEAT A-B / Yellow / YouTube / Repeat
Direct Navigator	LIST SMART / Smart / List	Blue	Prime Video RANDOM / Blue / Prime Video / Random
Menu	HOME MENU / Menu / Home	Stop	HOLD / Stop / Hold
EPG	-/-- GUIDE EPG / Guide / EPG / -/--	Pause	STEP-FREEZE / Pause / Step / Freeze
Exit	CLEAR EXIT CANCEL / Exit / Cancel / Clear	Play	SLOW / Play / Slow
Edit	PC FAV MARKER / Fav / Marker / PC	1	TV 1 / 1
<<	TUNE- / << / Tune-	2	DVD 2 / 2
>>	TUNE+ / >> / Tune+	3	CD-STB 3 / 3
Delete	RETURN BACK / Back / Return	4	VIDEO 4 / 4
Prog/Check	OPT-TOOLS SETUP / Setup / OPT / Tools	5	TAPE 5 / 5

Original		Rechange	
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
LIVE	Live	MEDIA DISPLAY	Display / Media
TV/RADIO	Tv/Radio	PROGRAM TV/RADIO	TV/Radio /
REC	Rec	REC MODE	Rec / Rec Mode
REC PAUSE	Rec Pause	SHIFT + STEP - FREEZE	Shift + Pause / Step /
VIEWER	Viewer	SIZE ZOOM	Zoom / Size
SKIP	Skip	RDS AV INPUT	AV / Input / RDS
BOOK SET	Set Book Mark	EQ SUBTITLE	Subtitle / EQ
MARK GO	Go Book Mark	SHIFT + PROGRAM TV/RADIO	Shift + TV/Radio / Program
VOLUME	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
TIMER REC	Timer Rec	TIMER SLEEP	Sleep / Timer
REPLAY	Replay	PRESET- ⏮	I<< / Preset-

Original		Rechange	
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
ASPECT	Aspect	FORMAT PICTURE	Picture / Format