# Mandis shop

Philips 996510032811

| Original | | Rechange | |
|---|---|---|---|
| | Power | | Power |
| | Eject | SURROUND | Eject / Surround |
| SEARCH | Search | NETFLIX SEARCH | Red / Netflix / Search |
| FAVORITE | Favorite | PC FAV MARKER | Fav / Marker / PC |
| | Up | | Up |
| | Left | | Left |
| | I<< | PRESET- | I<< / Preset- |
| OK | OK | OK | OK |
| | Right | | Right |
| | >>I | PRESET+ | >>I / Preset+ |
| BACK | Back | RETURN BACK | Back / Return |
| | Down | | Down |
| HOME | Home | HOME MENU | Menu / Home |
| | Mute | DIMMER MUTE | Mute / Dimmer |
| | Play | SLOW | Play / Slow |
| | Pause | STEP-FREEZE | Pause / Step / Freeze |
| | Stop | HOLD | Stop / Hold |

| Original | | Rechange | |
|---|---|---|---|
| | Vol - | VOL | Vol - |
| | Vol + | VOL | Vol + |
| ..?!'@ 1 | 1 | TV 1 | 1 |
| ABC 2 | 2 | DVD 2 | 2 |
| DEF 3 | 3 | CD-STB 3 | 3 |
| GHI 4 | 4 | VIDEO 4 | 4 |
| JKL 5 | 5 | TAPE 5 | 5 |
| MNO 6 | 6 | TUNER 6 | 6 |
| PQRS 7 | 7 | AUX-HDD 7 | 7 |
| TUV 8 | 8 | USB 8 | 8 |
| WXYZ 9 | 9 | BLUETOOTH 9 | 9 |
| a/A | a/A | MEDIA DISPLAY | Display / Media |
| 0 | 0 | HDMI-SAT 0 | 0 |
| CLEAR | Clear | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| SHUFFLE | Shuffle | LIST SMART | Smart / List |
| REPEAT | Repeat | APP REPEAT | Green / APP / Repeat |
| SOUND | Sound | TITLE SOUND | Sound / Title |

https://al-remotecontrol.fr/Philips/1553-790-telecommande-remplacement-pour-Philips-996510032811.html