Original	Rechange
CD	Shift + 3
TAPE	Shift + 5
VCR	Shift + 4
TUNER	Shift + 6
TXT	Text / Goto
DCC	Shift + 2
DSR	Shift + 7
DIG. REC	Shift + 8
TV	Shift + 1
Speakers A	Smart / List
Speakers B	Display / Media
Volume Audio +	Vol +
Volume Audio -	Vol -
Volume TV -	Left
Volume TV +	Right
Audio Processor	Down
Audio Processor	Up

Original	Rechange
TV	TV -/--
1	TV 1
2	TV 2
3	TV 3
4	TV 4
5	TV 5
6	TV 6
7	TV 7
8	TV 8
9	TV 9
0	TV 0
MUTE	TV Mute
PRESET TRACK	TV Preset +
PRESET TRACK	TV Preset -
STANDBY	TV Standby
HOLD STOP	TV-TXT Hold
MEMO OUT PLAY	TV-TXT Memo

Original		Rechange	
REVEAL	TV-TXT Reveal	SLOW	Play / Slow
CANCEL PAUSE	TV-TXT Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
TIME	TV-TXT Time	TIMER SLEEP	Sleep / Timer
ENLARGE MODE	TXT Enlarge	SIZE ZOOM	Zoom / Size
ENLARGE MODE	TV Mode	OK	OK
PRESET TRACK	TXT Preset +	CH PAGE +	CH+ / Page+
PRESET TRACK	TXT Preset -	CH PAGE -	CH- / Page-
STANDBY	DCC Standby	SHIFT +	Shift + Power
MUTE	DCC Mute	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
DECK A DISC	DCC Disc +	SHIFT + CH PAGE +	Shift + CH+ /
DISC DECK B	DCC Disc -	SHIFT + CH PAGE -	Shift + CH- /
PRESET TRACK	DCC Track +	SHIFT + PRESET+	Shift + >>I / Preset+
PRESET TRACK	DCC Track -	SHIFT + PRESET-	Shift + I<< / Preset-
HOLD STOP	DCC Stop	SHIFT + HOLD	Shift + Stop /
MEMO OUT PLAY	DCC Play	SHIFT + SLOW	Shift + Play /
REVEAL	DCC <<	SHIFT + TUNE-	Shift + << /
CANCEL PAUSE	DCC Pause	SHIFT + STEP-FREEZE	Shift + Pause / Step / Freeze

Original		Rechange	
TIME	DCC >>	SHIFT + TUNE+	Shift + >> /
ENLARGE MODE	DCC Mode	SHIFT + OK	Shift + OK
OPEN/CLOSE	DCC	SHIFT + SURROUND	Shift + Eject / Surround

Original		Rechange	
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
TAPE	TAPE	SHIFT + TAPE 5	Shift + 5
CD	CD	SHIFT + CD-STB 3	Shift + 3
TXT	TXT	GOTO TEXT	Text / Goto
TV	TV	SHIFT + TV 1	Shift + 1
DSR	DSR	SHIFT + AUX-HDD 7	Shift + 7
DCC	DCC	SHIFT + DVD 2	Shift + 2
DIG. REC	DIG. REC	SHIFT + USB 8	Shift + 8
A SPEAKERS	Speakers A	LIST SMART	Smart / List
SPEAKERS B	Speakers B	MEDIA DISPLAY	Display / Media
VOLUME AUDIO +	Volume Audio +	VOL +	Vol +
VOLUME AUDIO -	Volume Audio -	VOL -	Vol -
PROCESSOR +	Audio Processor	▲	Up
AUDIO PROC -	Audio Processor	▼	Down
VOLUME TV +	Volume TV +	▶	Right
VOLUME TV -	Volume TV -	◀	Left

Original		Rechange	
STANDBY	CD Standby	⏻	Power
1	CD 1	TV 1	1
2	CD 2	DVD 2	2
3	CD 3	CD-STB 3	3
4	CD 4	VIDEO 4	4
5	CD 5	TAPE 5	5
6	CD 6	TUNER 6	6
7	CD 7	AUX-HDD 7	7
8	CD 8	USB 8	8
9	CD 9	BLUETOOTH 9	9
0	CD 0	HDMI-SAT 0	0
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
DECK A DISC	CD Disc +	CH PAGE +	CH+ / Page+
DISC DECK B	CD Disc -	CH PAGE -	CH- / Page-
PRESET TRACK	CD Track +	PRESET+ ⏭	>>I / Preset+
PRESET TRACK	CD Track -	PRESET- ⏮	I<< / Preset-
HOLD STOP	CD Stop	HOLD ■	Stop / Hold

Original	Rechange	Original	Rechange
CD Play	Play / Slow		
CD <<	<< / Tune-		
CD Pause	Pause / Step / Freeze		
CD >>	>> / Tune+		
CD Mode	OK		
CD Open/Close	Eject / Surround		
DSR Standby	Shift + Power		
DSR Disc +	Shift + CH+ /		
DSR Disc -	Shift + CH- /		
DSR Preset/Track	Shift + >>I / Preset+		
DSR Preset/Track	Shift + I<< / Preset-		
DSR Mode	Shift + OK		

Original		Rechange	
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
TAPE	TAPE	SHIFT + TAPE 5	Shift + 5
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
CD	CD	SHIFT + CD-STB 3	Shift + 3
TV	TV	SHIFT + TV 1	Shift + 1
DCC	DCC	SHIFT + DVD 2	Shift + 2
DSR	DSR	SHIFT + AUX-HDD 7	Shift + 7
DIG. REC	DIG. REC	SHIFT + USB 8	Shift + 8
TXT	TXT	GOTO TEXT	Text / Goto
A SPEAKERS	Speakers A	LIST SMART	Smart / List
SPEAKERS B	Speakers B	MEDIA DISPLAY	Display / Media
VOLUME AUDIO +	Volume Audio +	VOL +	Vol +
VOLUME AUDIO -	Volume Audio -	VOL -	Vol -
VOLUME TV -	Volume TV -	◀	Left
VOLUME TV +	Volume TV +	▶	Right
AUDIO PROC -	Audio Processor	▼	Down
PROCESSOR +	Audio Processor	▲	Up

Original		Rechange	
1	TUNER 1	TV 1	1
2	TUNER 2	DVD 2	2
3	TUNER 3	CD-STB 3	3
4	TUNER 4	VIDEO 4	4
5	TUNER 5	TAPE 5	5
6	TUNER 6	TUNER 6	6
7	TUNER 7	AUX-HDD 7	7
8	TUNER 8	USB 8	8
9	TUNER 9	BLUETOOTH 9	9
0	TUNER 0	HDMI-SAT 0	0
STANDBY	TUNER Standby	⏻	Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PRESET TRACK +	TUNER Preset +	PRESET+ ▶▶|	>>I / Preset+
PRESET TRACK -	TUNER Preset -	PRESET- |◀◀	I<< / Preset-
REVEAL ◀◀	TUNER <<	TUNE- ◀◀	<< / Tune-
TIME ▶▶	TUNER >>	TUNE+ ▶▶	>> / Tune+
ENLARGE MODE	TUNER Mode	OK	OK

Original		Rechange			Original		Rechange
STANDBY	TAPE Standby	SHIFT	+	Shift + Power			
PRESET TRACK	TAPE Preset +	SHIFT	+	Shift + >>I / Preset+			
DECK A DISC	TAPE Deck A	SHIFT	+	Shift + Smart / List			
PRESET TRACK	TAPE Preset -	SHIFT	+	Shift + I<< / Preset-			
DISC DECK B	TAPE Deck B	SHIFT	+	Shift + Display / Media			
HOLD STOP	TAPE Stop	SHIFT	+	Shift + Stop /			
MEMO OUT PLAY	TAPE Play	SHIFT	+	Shift + Play /			
REVEAL	TAPE <<	SHIFT	+	Shift + << /			
TIME	TAPE >>	SHIFT	+	Shift + >> /			
ENLARGE MODE	TAPE Mode	SHIFT	+	Shift + OK			
RECORD	TAPE Record	SHIFT	+	Shift + Rec / Rec Mode			
CANCEL PAUSE	TAPE Pause	SHIFT	+	Shift + Pause / Step /			
OPEN/CLOSE	TAPE	SHIFT	+	Shift + Eject / Surround			

Original	Rechange	Original	Rechange
TAPE	Shift + 5	VCR 1	1
TUNER	Shift + 6	VCR 2	2
TXT	Text / Goto	VCR 3	3
VCR	Shift + 4	VCR 4	4
CD	Shift + 3	VCR 5	5
TV	Shift + 1	VCR 6	6
DCC	Shift + 2	VCR Standby	Power
DSR	Shift + 7	VCR 7	7
DIG. REC	Shift + 8	VCR 8	8
Speakers A	Smart / List	VCR 9	9
Speakers B	Display / Media	VCR 0	0
Volume Audio +	Vol +	VCR -/--	Guide / EPG / -/--
Volume Audio -	Vol -	VCR Mute	Mute / Dimmer
Volume TV -	Left	VCR Preset/Track	>>I / Preset+
Volume TV +	Right	VCR Preset/Track	I<< / Preset-
Audio Processor	Down	VCR Stop	Stop / Hold
Audio Processor	Up	VCR Play	Play / Slow

Original	Rechange	Original	Rechange
VCR <<	<< / Tune-		
VCR Pause	Pause / Step / Freeze		
VCR >>	>> / Tune+		
VCR Record	Rec / Rec Mode		
VCR Mode	OK		
VCR Open/Close	Eject / Surround		
DIG. REC	Shift + Power		
DIG. REC Mute	Shift + Mute / Dimmer		
DIG. REC Preset/Track +	Shift + >>I / Preset+		
DIG. REC Preset/Track -	Shift + I<< / Preset-		
DIG. REC Stop	Shift + Stop /		
DIG. REC Pause	Shift + Pause / Step /		
DIG. REC <<	Shift + << /		
DIG. REC >>	Shift + >> /		
DIG. REC Mode	Shift + OK		
DIG. REC Play	Shift + Play /		
DIG. REC Open/Close	Shift + Eject / Surround		