Original	Rechange
Power	Power
TV / Video	TV/R
DVD	Smart
VCR	Media
Open / Close	Eject
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Display	Info
Up	Up

Original	Rechange
Left	Left
OK	Ok
Right	Right
Down	Down
Stop	Stop
Play	Play
Pause / Step	Pause
<< REW	<<
>> FWD	>>
Record	Rec
Clear	Exit

Original		Rechange	
	Power		Power
	Open / Close		Eject
	DVD		Smart
	VCR		Media
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Return		Back
	Display		Info
	List / Disc Men		D. Menu

Original		Rechange	
	System Menu		Menu
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	I <		I <<
	>I		>>I
	Stop		Stop
	Play		Play
	Pause / Step		Pause
	<< REW		<<
	>> FWD		>>
	Thumbnail		3D
	Chapter		Format
	Timer		AV
	Record		Rec

Original		Rechange	
REC MODE	Rec. Mode	D	Blue
REPEAT	Repeat	REPEAT TEXT	Text
TITLE	Title	SETTINGS OPT	Options
AUDIO	Audio	SOUND DUAL	Dual
ZOOM	Zoom	SHIFT +	ZOOM Shift + Eject
SEARCH	Search	SEARCH TV/R	TV/R
MARKER	Marker	FAV PRE-CH	Pre Ch
D.DUBBING	D. Dubbing	-/-- GUIDE	Guide
CLEAR	Clear	CLEAR EXIT	Exit
SHOWVIEW VIDEOPLUS+	Showview / VideoPlus+	AD SUBT	Subt

Original	Rechange