Original	Rechange	Original	Rechange
Mute	Mute / Dimmer	6	6
Power	Power	A/B	Shift + Yellow / YouTube /
(↔)	Audio / Lang I/II	7	7
TV	TV/Radio /	8	8
_/	Sound / Title	9	9
[#]→	Picture / Format	Output	AV / Input / RDS
[.≡]	Text / Goto	-/--	Guide / EPG / -/--
[≡+]	Shift + Stop /	0	0
[≡♦]	Shift + Zoom /	C	Exit / Cancel / Clear
[≡x]◷	Back / Return	IN 123	D.Menu / Top
[≡?][+]	Sleep / Timer	1-/TP Off	Fav / Marker / PC
1	1	C00	Setup / OPT /
2	2	2-/TP On	Shift + Fav / Marker / PC
3	3	Vol +	Vol +
[≡i]	Info / Angle	Prog+	CH+ / Page+
4	4	Vol -	Vol -
5	5	Prog-	CH- / Page-

Original	Rechange	Original	Rechange
Red	Red / Netflix / Search	Contrast-	I << / Preset-
Green	Green / APP / Repeat	Brightness-	Shift + Left
Yellow	Yellow / YouTube / Repeat	Power Down	Shift + Power
Blue	Blue / Prime Video / Random	Prog- Down	Shift + CH- /
->	Display / Media	<<	<< / Tune-
-[<>]	Left	Play	Play / Slow
[<>]+	Right	>>	>> / Tune+
♦	Zoom / Size	Stop	Stop / Hold
(*)	Menu / Home	Pause	Pause / Step / Freeze
→ ←	Smart / List		
[II··]	OK		
[II··]+	Up		
[...]	Subtitle / EQ		
Contrast+	>>I / Preset+		
Brightness+	Shift + Right		
[II··]-	Down		
Prog+ Down	Shift + CH+ / Page+		

Original	Rechange	Original	Rechange
Power Down	Power		
Prog+ Down	CH+ / Page+		
Prog- Down	CH- / Page-		
Stop	Stop / Hold		
Pause	Pause / Step / Freeze		
Rec	Rec / Rec Mode		
>>	>> / Tune+		
Play	Play / Slow		
<<	<< / Tune-		

Original	Rechange	Original	Rechange
Power Down	Power		
Prog+ Down	CH+ / Page+		
Prog- Down	CH- / Page-		
Stop	Stop / Hold		
Pause	Pause / Step / Freeze		
Rec	Rec / Rec Mode		
>>	>> / Tune+		
Play	Play / Slow		
<<	<< / Tune-		

Original	Rechange	Original	Rechange
Power Down	Power		
Prog+ Down	CH+ / Page+		
Prog- Down	CH- / Page-		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
Stop	Stop / Hold		
Pause	Pause / Step / Freeze		
Rec	Rec / Rec Mode		