Original		Rechange		Original	Rechange
STAND BY	Standby		Power		
NEXT	>I		>>I		
PREVIOUS	I <		I <<		
SEARCH	>>		>>		
SEARCH	<<		<<		
VOLUME	Volume+	VOL +	Vol +		
VOLUME	Volume-	VOL –	Vol -		
PROG	Prog	PROG SLEEP	Sleep		
CD	CD	C	Yellow		
PHONO	Phono	A	Red		
TAPE	Tape	B	Green		
TUNER	Tuner	D	Blue		
BAND	Band	SEARCH TV/R	TV/R		
SCAN	Scan	APP MEDIA	Media		

Original		Rechange	
STAND BY	Standby		Power
PHONO	Phono	A	Red
TAPE	Tape	B	Green
CD	CD	C	Yellow
TUNER	Tuner	D	Blue
SHUFFLE	Shuffle	HOME SMART	Smart
DISC	Disc Up	+ CH	Ch +
DISC	Disc Down	CH −	Ch -
SCAN	Scan	APP MEDIA	Media
NEXT	>I	>>I	>>I
PREVIOUS	I<	I<<	I<<
REPEAT	Repeat	REPEAT TEXT	Text
PLAY / PAUSE	Play	PLAY MODE	Play
PLAY / PAUSE	Pause		Pause
STOP	Stop		Stop
PROG	Prog	PROG SLEEP	Sleep
VOLUME	Volume+	+ VOL	Vol +

Original		Rechange	
VOLUME	Volume-	VOL −	Vol -
SEARCH	<<	<<	<<
SEARCH	>>	>>	>>

Original		Rechange	
STAND BY	Standby		Power
PHONO	Phono	A	Red
TAPE	Tape	B	Green
CD	CD	C	Yellow
TUNER	Tuner	D	Blue
PREVIOUS	I <		I <<
NEXT	>I		>>I
VOLUME +	Volume+	VOL +	Vol +
VOLUME -	Volume-	VOL -	Vol -

Original	Rechange

Original		Rechange		Original	Rechange
STAND BY	Standby		Power		
PHONO	Phono	A	Red		
TAPE	Tape	B	Green		
CD	CD	C	Yellow		
TUNER	Tuner	D	Blue		
NEXT	>I		>>I		
PREVIOUS	I <		I <<		
SEARCH	<<		<<		
SEARCH	>>		>>		
STOP	Stop		Stop		
PLAY / PAUSE	Play	PLAY MODE	Play		
PLAY / PAUSE	Pause		Pause		
VOLUME	Volume+	VOL +	Vol +		
VOLUME	Volume-	VOL −	Vol -		