Mandis shop

Philips CRP763-01

| Original | | Rechange | | Original | Rechange |
|---|---|---|---|---|---|
| POWER | Power | | Power | | |
| ▶/II | Play | SLOW | Play / Slow | | |
| ▶/II | Pause | STEP-FREEZE | Pause / Step / Freeze | | |
| TURBO | Turbo | LIST SMART | Smart / List | | |
| BASE | Base | MEDIA DISPLAY | Display / Media | | |
| CLOCK | Clock | PROGRAM TV/RADIO | TV/Radio / | | |
| TIMER | Timer | TIMER SLEEP | Sleep / Timer | | |
| TIME | Time- | CH PAGE | CH- / Page- | | |
| TIME | Time+ | CH PAGE | CH+ / Page+ | | |
| MODE | Mode | FORMAT PICTURE | Picture / Format | | |
| | Up | | Up | | |
| | Left | | Left | | |
| ENTER | Enter | OK | OK | | |
| | Right | | Right | | |
| | Down | | Down | | |
| | | | | | |
| | | | | | |

https://all-remote-controls.nl/fr/Philips/10728-8524-telecommande-replacement-pour-Philips-CRP763-01-42245461.htm