Mandis shop

CU-CLD095

Original		Rechange	
POWER	Power		Power
16:9		FORMAT PICTURE	Picture / Format
Stop/Eject		HOLD	Stop / Hold
Audio		LANG I/II AUDIO	Audio / Lang I/II
◁I Step			Left
Step II▷			Right
I<< Skip		PRESET-	I<< / Preset-
Skip >>I		PRESET+	>>I / Preset+
Pause		STEP-FREEZE	Pause / Step / Freeze
Play		SLOW	Play / Slow
<< Scan		TUNE-	<< / Tune-
Scan >>		TUNE+	>> / Tune+
Q/A/CX		-/-- GUIDE EPG	Guide / EPG / -/--
Random		Prime Video RANDOM	Blue / Prime Video / Random
Hilite/Intro		OK	OK
D-Level CTRL		LIST SMART	Smart / List
+		VOL	Vol +

Original		Rechange	
-		VOL	Vol -
Display		MEDIA DISPLAY	Display / Media
Multi-Speed >		CH PAGE	CH+ / Page+
< Multi-Speed		CH PAGE	CH- / Page-
Clear		CLEAR EXIT CANCEL	Exit / Cancel / Clear
Repeat A		NETFLIX SEARCH	Red / Netflix / Search
Repeat B		APP REPEAT	Green / APP / Repeat

https://al-remotecontrols.fr/Pioneer/1053-958-Telecommande-remplacement-pour-Pioneer-CLD095.htm