Original	Rechange
Power	Power
Function	Menu / Home
Volume-	Vol -
Volume+	Vol +
Flat	Sound / Title
Surr & ST Wide	Audio / Lang I/II
Smart EQ	Subtitle / EQ
Effect On/Off	Picture / Format
FM Mono	Red / Netflix / Search
Station Up	CH+ / Page+
GEQ On/Off	Eject / Surround
Station Down	CH- / Page-
Random CD	Blue / Prime Video / Random
Pause CD	Pause / Step / Freeze
Play CD	Play / Slow
PGM CD	TV/Radio /
Sleep	Sleep / Timer

Original	Rechange
Wake Up	Back / Return
Snooze	Info / Angle
Deck I >	Right
< Deck I	Left
>> Deck I	Up
<< Deck I	Down
Stop Deck I	OK
Rec Deck II	Rec / Rec Mode
Deck II >	Shift + Right
< Deck II	Shift + Left
<< Deck II	Shift + Down
>> Deck II	Shift + Up
Stop Deck II	Shift + OK
Pause Deck II	Shift + Pause / Step /
Stop CD	Stop / Hold
Disc CD	Yellow / YouTube / Repeat
I << CD	I << / Preset-

Original	Rechange	Original	Rechange
>>I CD	PRESET+ >>I / Preset +		