# Mandis shop

ROTEL RR927- AMP2

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Standby AMP | Power | Vol - | Vol - |
| Phono | 1 | On Screen | Options |
| Tuner | AV | CTR FCS | Guide |
| AUX1 | 2 | < SRND Mode | Ch - |
| AUX 2 | 3 | SRND Mode > | Ch + |
| Tape 1 | 4 | BAL CHK | Dual |
| Tape 2 | 5 | < Delay Time | Down |
| Video 1 | 6 | Delay Time > | Up |
| Video 2 | 7 | >> Tape | >> |
| Video 3 | 8 | << Tape | << |
| Off | Exit | Play Tape | Play |
| Rec/Zone | List | Pause Tape | Pause |
| Band | 0 | Rec Tape | Rec |
| A Tun | Pre Ch | Stop Tape | Stop |
| < Tuning | Left | | |
| Tuning > | Right | | |
| Vol + | Vol + | | |

https://all-remote-controls.nl/fr/ROTEL/16184675-telecommande-replacement-pour-ROTEL-RR927-AMP2.htm