Original		Rechange	
STANDBY	Standby		Power
TELETEXT	Teletex	TEXT	TEXT
	Red	A	Red (A)
SMART	Green/[ ] Smart	B	Green (B)
SMART	Yellow/♪ Smart	C	Yellow (C)
	Blue	D	Blue (D)
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
CLEAR	Clear	EXIT	EXIT

Original		Rechange	
TIMER	Timer	EPG	-/-- / EPG
MENU	Menu	MENU	MENU
	Mute		MUTE
P<P	P<P	FAV	P/C / FAV
OK	OK	OK	OK
P+	Up		UP
P-	Down		DOWN
	Right		RIGHT
	Left		LEFT
P+	P+	CH	CH +
P-	P-	CH	CH -
	Vol +	VOL	VOL +
	Vol -	VOL	VOL -
PLAY	Play		Play
STOP	Stop		Stop
RECORD/OTR	Record/OTR		Rec
	<<		Rewind

Original		Rechange		Original	Rechange
	>>		Fast Forward		
INDEX	>I / Index		Last		
STILL	>I </ Still		Pause		