Original	Rechange	Original	Rechange
Power	Power	Left	Left
Mute	Mute / Dimmer	Enter	OK
1	1	Right	Right
2	2	Menu	Menu / Home
3	3	Down	Down
4	4	Exit	Exit / Cancel / Clear
5	5	Vol +	Vol +
6	6	List	Smart / List
7	7	CH +	CH+ / Page+
8	8	Vol -	Vol -
9	9	CH -	CH- / Page-
Source	AV / Input / RDS	Fav	Fav / Marker / PC
0	0	Sleep	Sleep / Timer
Info	Info / Angle	Index	Display / Media
DMP	D.Menu / Top	Recall	Back / Return
Up	Up	Red / <<	Red / Netflix / Search
EPG	Guide / EPG / -/--	Red / <<	<< / Tune-

Original	Rechange	Original	Rechange
Green / >>	>> / Tune+		
Green / >>	Green / APP / Repeat		
Yellow / I<<	I<< / Preset-		
Yellow / I<<	Yellow / YouTube / Repeat		
Blue / >>I	Blue / Prime Video / Random		
Blue / >>I	>>I / Preset+		
Text / Play/Paus	Text / Goto		
Text / Play/Paus	Pause / Step / Freeze		
Text / Play/Paus	Play / Slow		
Stop / Still	Stop / Hold		
Timer / Subtitl	Subtitle / EQ		
Size / Aspect	Zoom / Size		
Cancel [=X]	SHIFT + CLEAR EXIT CANCEL Shift + Exit / Cancel / Clear		
Radio	TV/ Radio /		
Audio / I/II	Audio / Lang I/II		
Rec	Rec / Rec Mode		

Original	Rechange	Original	Rechange
Power	Power	Left	Left
Mute	Mute / Dimmer	Enter	OK
1	1	Right	Right
2	2	Menu	Menu / Home
3	3	Down	Down
4	4	Exit	Exit / Cancel / Clear
5	5	Vol +	Vol +
6	6	List	Smart / List
7	7	CH+	CH+ / Page+
8	8	Vol -	Vol -
9	9	CH-	CH- / Page-
[≡?] / Source	AV / Input / RDS	♥	Fav / Marker / PC
0	0	Sleep	Sleep / Timer
[≡i] / Info	Info / Angle	Index	Display / Media
DMP	D.Menu / Top	Back	Back / Return
Up	Up	Red	Red / Netflix / Search
EPG	Guide / EPG / -/--	<<	<< / Tune-

Original	Rechange	Original	Rechange
Green	Green / APP / Repeat		
>>	>> / Tune+		
Yellow	Yellow / YouTube / Repeat		
I<<	I<< / Preset-		
Blue	Blue / Prime Video / Random		
>>I	>>I / Preset+		
Play	Play / Slow		
Pause	Pause / Step / Freeze		
[≡]	Text / Goto		
Stop/Still	Stop / Hold		
[≡+]	Picture / Format		
[≡o]/Subtitle	Subtitle / EQ		
[≡♦]/[+]	Zoom / Size		
[≡x]	Setup / OPT /		
Radio	TV/Radio /		
Audio	Audio / Lang I/II		
Rec	Rec / Rec Mode		