Original		Rechange	
	Power		Power
	Open/Close	ZOOM	Eject
FUNCTION	Function	APP MEDIA	Media
	[I]/PLII	SOUND DUAL	Dual
MUTE	Mute	MUTE	Mute
DSP/EQ	DSP/EQ	AD SUBT	Subt
S.VOL 1	1/S. Vol	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
P.SCAN 7	7/P. Scan	7	7
8	8	8	8
9	9	9	9
0	0	0	0
VOL +	Vol +	+ VOL	Vol +

Original		Rechange	
VOL −	Vol -	VOL −	Vol -
	I<<		I<<
	>>I		>>I
	<<		<<
	>>		>>
	Stop		Stop
	Play	PLAY MODE	Play
	Pause		Pause
DISC MENU	Disc Menu	E-MANUAL D.MENU	D. Menu
HOME	Home	HOME SMART	Smart
TITLE MENU	Title Menu	TOP MENU MENU	Menu
TOOLS	Tools	SETTINGS OPT	Options
INFO	Info	DISPLAY INFO	Info
RETURN	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
TUNING	Up		Up
TUNING	Tuning Up	+ CH	Ch +

Original		Rechange	
	Down		Down
	Tuning Down	CH –	Ch -
	Right		Right
	Left		Left
	OK	OK	Ok
AUDIO UPSCALE P.BASS A	Red/ Audio Upscale/ P. Bass	A	Red
S/W LEVEL B	Green/ S/ W	B	Green
GIGA C	Yellow/ Giga	C	Yellow
MO/ST D	Blue/ Mb/ St	D	Blue
USB REC	USB Rec	REC MODE	Rec
DIMMER	Dimmer	TIMER AV	AV
REPEAT	Repeat	REPEAT TEXT	Text
TUNER MEMORY	Tuner Memory	SEARCH TV/R	TV/ R

Original	Rechange