Mandis shop

RC4870

Original	Rechange
Power	Power
Mute	Mute / Dimmer
Play	Play / Slow
Pause	Pause / Step / Freeze
Stop	Stop / Hold
Rec	Rec / Rec Mode
<<	<< / Tune-
>>	>> / Tune+
Lang	Audio / Lang I/II
Source (Games)	Eject / Surround
Movie-Music-Phot	Picture / Format
[≡] . .	Zoom / Size
*/O	Sleep / Timer
TV	TV/Radio /
Q. Menu	D. Menu / Top
[- O-]	Setup / OPT /
[≡] / Text	Text / Goto

Original	Rechange
Menu	Menu / Home
Up	Up
i	Info / Angle
Left	Left
OK	OK
Right	Right
Exit	Exit / Cancel / Clear
Down	Down
Back	Back / Return
Vol +	Vol +
World (Violet)	Smart / List
PR+	CH+ / Page+
Vol -	Vol -
*/Q	Display / Media
PR-	CH- / Page-
1	1
2	2

Original		Rechange		Original	Rechange
	3	CD - STB 3	3		
	4	VIDEO 4	4		
	5	TAPE 5	5		
	6	TUNER 6	6		
	7	AUX - HDD 7	7		
../@	8	USB 8	8		
	9	BLUETOOTH 9	9		
	Guide	-/-- GUIDE EPG	Guide / EPG / -/--		
	0	HDMI - SAT 0	0		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
	Recall	SHIFT + RETURN BACK	Shift + Back / Return		