Original		Rechange	
I/⏻	Power	⏻	Power
Source	Source	TIMER AV	AV
TrackID	TrackID	SEARCH TV/R	TV/R
i-MANUAL ?	?/i - Manual	E-MANUAL D.MENU	D. Menu
3D	3D	ECO 3D	3D
[+]	[+]	PICTURE FORMAT	Format
DIGITAL/ ANALOG	Digital / Analog	DISC NAV LIST	List
EXIT	Exit	CLEAR EXIT	Exit
SCENE	Scene	FAV PRE-CH	Pre Ch
INTERNET VIDEO	Internet / Video	APP MEDIA	Media
⏮	I <<	⏮	I <<
⏸	Pause	⏸	Pause
⏭	>>I	⏭	>>I
⏪	<<	⏪	<<
▶	Play	PLAY MODE ▶	Play
⏩	>>	⏩	>>
■	Stop	■	Stop

Original		Rechange	
REC ●	Rec	REC MODE ●	Rec
SYNC MENU	Sync Menu	TOP MENU MENU	Menu
HOME	Home	HOME SMART	Smart
?	[i +] / [?]	DISPLAY INFO	Info
OPTIONS	Options	SETTINGS OPT	Options
GUIDE	Guide	-/-- GUIDE	Guide
RETURN BACK	Return/ Back	RETURN BACK	Back
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
✥	OK	OK	Ok
▬	Red	A	Red
▬	Green	B	Green
▬	Yellow	C	Yellow
▬	Blue	D	Blue
1	1	1	1

Original		Rechange		Original	Rechange
2	2	2	2		
3	3	3	3		
4	4	4	4		
5	5	5	5		
6	6	6	6		
7	7	7	7		
8	8	8	8		
9	9	9	9		
0	0	0	0		
	[≡]	REPEAT TEXT	Text		
	[. . .]	AD SUBT	Subt		
+	Vol +	+ VOL	Vol +		
–	Vol -	VOL –	Vol -		
	Mut e	MUTE	Mut e		
PROG +	Pr og/ CH+	+ CH	Ch +		
– CH	Pr og/ CH-	CH –	Ch -		
AUDIO	Audi o	SOUND DUAL	Dual		