Original		Rechange	
I/⏻	Power	⏻	Power
SOCIAL VIEW	Social View	APP MEDIA	Media
Input		TIMER AV	AV
DIGITAL/ ANALOG	Digital / Analog	ZOOM ⏏	Eject
EXIT	Exit	CLEAR EXIT	Exit
FOOTBALL	Football	DISC NAV LIST	List
3D	3D	ECO 3D	3D
1 ./	1	1	1
2abc	2	2	2
3def	3	3	3
4 ghi	4	4	4
5 jkl	5	5	5
6mno	6	6	6
7pqrs	7	7	7
8 tuv	8	8	8
9 wxyz	9	9	9
0 ␣	0	0	0

Original		Rechange	
RADIO TV	TV/ Radio	SEARCH TV/R	TV/ R
[≡]		REPEAT TEXT	Text
Red		A	Red
Green		B	Green
Yellow		C	Yellow
Blue		D	Blue
RELATED SEARCH TrackID	X/ Related Search/ Track ID	SHIFT +	SEARCH TV/R Shift + TV/ R
SYNC MENU	Sync Menu	TOP MENU MENU	Menu
i-MANUAL ?	?/ i - Manual	E-MANUAL D.MENU	D. Menu
DISCOVER	Discover	PROG SLEEP	Sleep
[i +]/ [?]		DISPLAY INFO	Info
RETURN	Return/ Back	RETURN BACK	Back
OPTIONS	Options	SETTINGS OPT	Options
HOME	Home	HOME SMART	Smart
GUIDE	Guide	-/-- GUIDE	Guide
	Up	▲	Up
	Down	▼	Down

Original	Rechange
Right	Right
Left	Left
OK	Ok
Vol +	Vol +
Vol -	Vol -
Mute	Mute
Recall	Pre Ch
Prog+	Ch +
Prog-	Ch -
Audio	Dual
[. . .]	Subt
[+]	Format
<<	<<
Play	Play
>>	>>
I <<	I <<
Pause	Pause

Original	Rechange
>>I	>>I
Rec	Rec
Stop	Stop
Tv Pause	Shift + Pause