Mandis shop

RMT-CS200AD

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Operate (AC Only) | Power | | |
| Function | Menu | | |
| Band | TV/R | | |
| Play/Pause | Play | | |
| Play | Yellow | | |
| Pause | Pause | | |
| >>I/Preset+ | >>I | | |
| >>/Tune+ | >> | | |
| I<</Preset- | I<< | | |
| <</Tune- | << | | |
| Stop | Stop | | |
| Vol+ | Vol + | | |
| Vol- | Vol - | | |
| | | | |
| | | | |
| | | | |
| | | | |

https://all-remote-controls.nl/fr/Sony/1062926-91480-telecommande-de-remplacement-pour-Sony-RMT-CS200AD.html