Original		Rechange	
	Power		Power
5 PROG	Prog+	CH PAGE +	CH+ / Page+
	Prog-	CH PAGE −	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
TV/VTR	Tv/ VTR	PROGRAM TV/ RADIO	TV/ Radi o /
VOL +	Vol +	+ VOL	Vol +
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
DATA SCREEN	Dat a Scr een	MEDIA DISPLAY	Di spl ay / Medi a
VOL -	Vol -	VOL −	Vol -
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
-/--	- / - -	-/-- GUIDE EPG	Gui de / EPG / - / - -

Original		Rechange	
0	0	HDMI - SAT 0	0

Original		Rechange	
CHECK	Check	LIST SMART	Smart / List
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
(ON/OFF)	On/Off Timer/Rec	TIMER SLEEP	Sleep / Timer
	Power		Power
5 PROG	Prog+	CH PAGE +	CH+ / Page+
	Prog-	CH PAGE −	CH- / Page-
6 TRANSMIT	Transmit	NETFLIX SEARCH	Red / Netflix / Search
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
REC MODE	Rec Mode	SHIFT + REC MODE	Shift + Rec / Rec Mode
TV/VTR	Tv/VTR	PROGRAM TV/RADIO	TV/Radio /
VOL +	Vol +	VOL +	Vol +
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
DATA SCREEN	Data Screen	MEDIA DISPLAY	Display / Media

Original		Rechange	
INPUT SELECT	Input Select	RDS AV INPUT	AV / Input / RDS
VOL −	Vol -	VOL −	Vol -
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
TIMER ON SCREEN	Timer On	APP REPEAT	Green / APP / Repeat
COUNTER RESET	Counter Reset	YouTube REPEAT A-B	Yellow / YouTube / Repeat
INDEX	Index	ANGLE INFO	Info / Angle
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI-SAT 0	0
▲	Up	▲	Up
PinP	PinP	FORMAT PICTURE	Picture / Format
SHIFT	Shift	GOTO TEXT	Text / Goto
DIGITAL OFF	Digital Off	SIZE ZOOM	Zoom / Size
MENU	Menu	HOME MENU	Menu / Home
◀	Left	◀	Left
EXECUTE	Execute	OK	OK

Original	Rechange	Original	Rechange
Right	Right	>>/ FF	>> / Tune+
Edit Monitor	Subtitle / EQ	Search >>	>>I / Preset+
Index Mark	Setup / OPT /	Stop	Stop / Hold
Index Erase	Fav / Marker / PC		
Down	Down		
< Frame	Shift + Left		
>I < Frame	Shift + OK		
Frame >	Shift + Right		
Pause	Pause / Step / Freeze		
Rec	Rec / Rec Mode		
Slow-	Shift + CH- /		
Slow+	Shift + CH+ /		
Audio Dub	Audio / Lang I/II		
Play	Play / Slow		
<<< High Speed Remain	Back / Return		
<< Search	I << / Preset-		
<<< REW	<< / Tune-		

Original		Rechange	
CHECK	Check	LIST SMART	Smart / List
TIMER REC CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
(ON/OFF)	On/Off Timer Rec	TIMER SLEEP	Sleep / Timer
	Power		Power
5 PROG	Prog+	+ CH PAGE	CH+ / Page+
	Prog-	CH PAGE −	CH- / Page-
6 TRANSMIT	Transmit	NETFLIX SEARCH	Red / Netflix / Search
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
REC MODE	Rec Mode	SHIFT + REC MODE	Shift + Rec / Rec Mode
TV/VTR	Tv/VTR	PROGRAM TV/ RADIO	TV/Radio /
VOL +	Vol +	+ VOL	Vol +
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
DATA SCREEN	Data Screen	MEDIA DISPLAY	Display / Media

Original		Rechange	
INPUT SELECT	Input Select	RDS AV INPUT	AV / Input / RDS
VOL −	Vol -	VOL −	Vol -
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
TIMER ON SCREEN	Timer On	APP REPEAT	Green / APP / Repeat
COUNTER RESET	Counter Reset	YouTube REPEAT A-B	Yellow / YouTube / Repeat
INDEX	Index	ANGLE INFO	Info / Angle
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
▲	Up	▲	Up
PinP	PinP	FORMAT PICTURE	Picture / Format
SHIFT	Shift	GOTO TEXT	Text / Goto
DIGITAL OFF	Digital Off	SIZE ZOOM	Zoom / Size
MENU	Menu	HOME MENU	Menu / Home
◀	Left	◀	Left
EXECUTE	Execute	OK	OK

Original		Rechange	
	Right		Right
EDIT MONITOR	Edit Monitor	EQ SUBTITLE	Subtitle / EQ
INDEX MARK	Index Mark	OPT-TOOLS SETUP	Setup / OPT /
INDEX ERASE	Index Erase	PC FAV MARKER	Fav / Marker / PC
	Down		Down
	< Frame	SHIFT +	Shift + Left
FRAME	>I < Frame	SHIFT + OK	Shift + OK
	Frame >	SHIFT +	Shift + Right
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
REC	Rec	REC MODE	Rec / Rec Mode
SLOW	Slow-	SHIFT + CH PAGE −	Shift + CH- /
SLOW	Slow+	SHIFT + CH PAGE +	Shift + CH+ /
AUDIO DUB	Audio Hub	LANG I/II AUDIO	Audio / Lang I/II
PLAY	Play	SLOW	Play / Slow
HIGH SPEED REWIND	<<< High Speed Remain	RETURN BACK	Back / Return
SEARCH	<< search	PRESET-	I << / Preset-
REW	<<< REW	TUNE-	<< / Tune-

Original		Rechange	
FF	>>/ FF	TUNE+	>> / Tune+
SEARCH	Search >>	PRESET+	>>I / Preset+
STOP	Stop	HOLD	Stop / Hold

Original		Rechange	
CHECK	Check	LIST SMART	Smart / List
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
(ON/OFF)	On/Off Timer Rec	TIMER SLEEP	Sleep / Timer
	Power		Power
5 PROG	Prog+	+ CH PAGE	CH+ / Page+
	Prog-	CH PAGE −	CH- / Page-
6 TRANSMIT	Transmit	NETFLIX SEARCH	Red / Netflix / Search
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
REC MODE	Rec Mode	SHIFT + REC MODE	Shift + Rec / Rec Mode
TV/VTR	Tv/VTR	PROGRAM TV/RADIO	TV/Radio /
VOL +	Vol +	+ VOL	Vol +
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
DATA SCREEN	Data Screen	MEDIA DISPLAY	Display / Media

Original		Rechange	
INPUT SELECT	Input Select	RDS AV INPUT	AV / Input / RDS
VOL −	Vol -	VOL −	Vol -
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
TIMER ON SCREEN	Timer On	APP REPEAT	Green / APP / Repeat
COUNTER RESET	Counter Reset	YouTube REPEAT A-B	Yellow / YouTube / Repeat
INDEX	Index	ANGLE INFO	Info / Angle
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
▲	Up	▲	Up
PinP	PinP	FORMAT PICTURE	Picture / Format
SHIFT	Shift	GOTO TEXT	Text / Goto
DIGITAL OFF	Digital Off	SIZE ZOOM	Zoom / Size
MENU	Menu	HOME MENU	Menu / Home
◀	Left	◀	Left
EXECUTE	Execute	OK	OK

Original		Rechange	
	Right		Right
EDIT MONITOR	Edit Monitor	EQ SUBTITLE	Subtitle / EQ
INDEX MARK	Index Mark	OPT-TOOLS SETUP	Setup / OPT /
INDEX ERASE	Index Erase	PC FAV MARKER	Fav / Marker / PC
	Down		Down
	< Frame	SHIFT +	Shift + Left
FRAME	>I < Frame	SHIFT + OK	Shift + OK
	Frame >	SHIFT +	Shift + Right
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
REC	Rec	REC MODE	Rec / Rec Mode
SLOW	Slow-	SHIFT + CH PAGE −	Shift + CH- /
SLOW	Slow+	SHIFT + CH PAGE +	Shift + CH+ /
AUDIO DUB	Audio Dub	LANG I/II AUDIO	Audio / Lang I/II
PLAY	Play	SLOW	Play / Slow
HIGH SPEED REWIND	<<</ High Speed Rewind	RETURN BACK	Back / Return
SEARCH	<< Search	PRESET-	I << / Preset-
REW	<</ REW	TUNE-	<< / Tune-

Original		Rechange	
FF	>>/ FF	TUNE+	>> / Tune+
SEARCH	Search >>	PRESET+	>>I / Preset+
STOP	Stop	HOLD	Stop / Hold