Original		Rechange	
	Power		Power
	Premium On	HOME SMART	Smart
Guida	Guida	-/-- GUIDE	Guide
Lista	Lista	DISC NAV LIST	List
Info	Info	DISPLAY INFO	Info
vol +	Vol +	+ VOL	Vol +
vol -	Vol -	VOL -	Vol -
prog +	Prog+	+ CH	Ch +
prog -	Prog-	CH -	Ch -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
Back	Back	RETURN BACK	Back
STOP Exit	Exit	CLEAR EXIT	Exit
STOP Exit	Stop		Stop

Original		Rechange	
PAUSE/PLAY	Play	PLAY MODE	Play
PAUSE/PLAY	Pause		Pause
FWD	>>		>>
REW	<<		<<
.,;@ 1	1	1	1
abc 2	2	2	2
def 3	3	3	3
ghi 4	4	4	4
jkl 5	5	5	5
mno 6	6	6	6
pqrs 7	7	7	7
tuv 8	8	8	8
wxyz 9	9	9	9
0	0	0	0
Menu	Menu	TOP MENU MENU	Menu
Opzioni	Opzioni	SETTINGS OPT	Options
TEXT	Text	REPEAT TEXT	Text

Original		Rechange	
APP	APP	APP MEDIA	Medi a
	Red	A	Red
TEXT	Gr een	B	Gr een
APP	Yel l ow	C	Yel l ow
	Bl ue/ Recal l	D	Bl ue

Original	Rechange