Original	Rechange	Original	Rechange
Power TV	Power	Up TV	Up
Mute TV TV	Mute / Dimmer	Left/RDS TV	Left
Play/Save TV	Play / Slow	OK TV	OK
Pause TV	Pause / Step / Freeze	Right/PTY TV	Right
Stop TV	Stop / Hold	Clear TV	Exit / Cancel / Clear
Rec TV	Rec / Rec Mode	Down TV	Down
<</Tuner- TV	<< / Tune-	Back/ST-Mono	Back / Return
>>/Tuner+ TV	>> / Tune+	Vol + TV TV	Vol +
PR-/I << TV	I << / Preset-	PR+/>>I TV	CH+ / Page+
PR+/>>I TV	>>I / Preset+	Vol - TV TV	Vol -
Level TV	Sound / Title	PR-/I << TV	CH- / Page-
Subwoofer TV	Audio / Lang I/II	1 Tv	1
Equalizer TV	Subtitle / EQ	2 TV	2
Surround TV	Eject / Surround	3 TV	3
Night TV	Sleep / Timer	4 TV	4
Setup TV	Setup / OPT /	5 TV	5
Menu TV TV	Menu / Home	6 TV	6

Original	Rechange
7 TV	7
8 TV	8
9 TV	9
Guide TV	Guide / EPG / -/--
0 TV	0
Tape- CD	Red / Netflix / Search
AUX1 (VCR)	Green / APP / Repeat
Aux2 (SAT- Cable	Yellow / YouTube / Repeat
Power AUX1	Shift + Power
Play/ Save AUX1	Shift + Play /
Pause AUX1	Shift + Pause / Step /
Stop AUX1	Shift + Stop /
Rec AUX1	Shift + Rec / Rec Mode
<</ Tuner -	Shift + << /
>>/ Tuner +	Shift + >> /
PR- / I <<AUX1	Shift + I << / Preset-
PR+/ >>I AUX1	Shift + >>I / Preset+

Original	Rechange
Up AUX1	Shift + Up
Left / RDS AUX1	Shift + Left
OK AUX1	Shift + OK
Right / PTY AUX1	Shift + Right
Down AUX1	Shift + Down
PR+/ >>I AUX1	Shift + CH+ /
PR- / I <<AUX1	Shift + CH- /
1 AUX1	Shift + 1
2 AUX1	Shift + 2
3 AUX1	Shift + 3
4 AUX1	Shift + 4
5 AUX1	Shift + 5
6 AUX1	Shift + 6
7 AUX1	Shift + 7
8 AUX1	Shift + 8
9 AUX1	Shift + 9
Guide AUX1	Shift + Guide / EPG / -/--

Original	Rechange	Original	Rechange
0 AUX1	SHIFT + HDMI - SAT 0 Shift + 0		

Original	Rechange	Original	Rechange
Power DVD6CH	Power	Up DVD6CH	Up
Mute DVD6CH	Mute / Dimmer	Left / RDS	Left
Play/ Save	Play / Slow	OK DVD6CH	OK
Pause DVD6CH	Pause / Step / Freeze	Right / PTY	Right
Stop DVD6CH	Stop / Hold	Clear DVD6CH	Exit / Cancel / Clear
Rec DVD6CH	Rec / Rec Mode	Down DVD6CH	Down
<</ Tuner-	<< / Tune-	Back/ St-Mono	Back / Return
>>/ Tuner+	>> / Tune+	Vol + DVD6CH	Vol +
PR- / I <<	I << / Preset-	PR+/ >>I	CH+ / Page+
PR+/ >>I	>>I / Preset+	Vol - DVD6CH	Vol -
Level DVD6CH	Sound / Title	PR- / I <<	CH- / Page-
Subwoofer	Audio / Lang I/II	1 DVD6CH	1
Equalizer	Subtitle / EQ	2 DVD6CH	2
Surround	Eject / Surround	3 DVD6CH	3
Night DVD6CH	Sleep / Timer	4 DVD6CH	4
Setup DVD6CH	Setup / OPT /	5 DVD6CH	5
Menu DVD6CH	Menu / Home	6 DVD6CH	6

Original	Rechange	Original	Rechange
7 DVD6CH	7	Up Tape- CD	Shift + Up
8 DVD6CH	8	Left / RDS Tape- CD	Shift + Left
9 DVD6CH	9	OK Tape- CD	Shift + OK
Guide DVD6CH	Guide / EPG / -/--	Right / PTY	Shift + Right
0 DVD6CH	0	Down Tape- CD	Shift + Down
Tape- CD	Red / Netflix / Search	Back/ ST- Mono Tape- CD	Shift + Back / Return
AUX1 (VCR)	Green / APP / Repeat	PR+/ >>I	Shift + CH+ /
Aux2 (SAT- Cable	Yellow / YouTube / Repeat	PR- / I <<	Shift + CH- /
Power Tape- CD	Shift + Power	1 Tape- CD	Shift + 1
Play/ Save	Shift + Play /	2 Tape- CD	Shift + 2
Pause Tape- CD	Shift + Pause / Step /	3 Tape- CD	Shift + 3
Stop Tape- CD	Shift + Stop /	4 Tape- CD	Shift + 4
Rec Tape- CD	Shift + Rec / Rec Mode	5 Tape- CD	Shift + 5
<</ Tuner -	Shift + << /	6 Tape- CD	Shift + 6
>>/ Tuner +	Shift + >> /	7 Tape- CD	Shift + 7
PR- / I <<	Shift + I << / Preset-	8 Tape- CD	Shift + 8
PR+/ >>I	Shift + >>I / Preset+	9 Tape- CD	Shift + 9

Tape- CD

Original	Rechange	Original	Rechange
0 Tape- CD	SHIFT + HDMI - SAT 0 Shift + 0		

Original	Rechange	Original	Rechange
Power TUNER	Power	Left / RDS TUNER	Left
Mute TUNER	Mute / Dimmer	OK TUNER	OK
Play / Save	Play / Slow	Right / PTY	Right
Pause TUNER	Pause / Step / Freeze	Clear TUNER	Exit / Cancel / Clear
Stop TUNER	Stop / Hold	Down TUNER	Down
<< / Tuner-	<< / Tune-	Back / St-Mono	Back / Return
>> / Tuner+	>> / Tune+	Vol + TUNER	Vol +
PR- / I << TUNER	I << / Preset-	PR+ / >>I TUNER	CH+ / Page+
PR+ / >>I TUNER	>>I / Preset+	Vol - TUNER	Vol -
Level TUNER	Sound / Title	PR- / I << TUNER	CH- / Page-
Subwoofer	Audio / Lang I/II	1 TUNER	1
Equalizer	Subtitle / EQ	2 TUNER	2
Surround	Eject / Surround	3 TUNER	3
Night TUNER	Sleep / Timer	4 TUNER	4
Setup TUNER	Setup / OPT /	5 TUNER	5
Menu TUNER	Menu / Home	6 TUNER	6
Up TUNER	Up	7 TUNER	7

Original	Rechange
8 TUNER	8
9 TUNER	9
Guide TUNER	Guide / EPG / -/--
0 TUNER	0
Tape- CD	Red / Netflix / Search
AUX1 (VCR)	Green / APP / Repeat
Aux2 (SAT- Cable	Yellow / YouTube / Repeat
Power AUX2	Shift + Power
Play/ Save AUX2	Shift + Play /
Pause AUX2	Shift + Pause / Step /
Stop AUX2	Shift + Stop /
Rec AUX2	Shift + Rec / Rec Mode
<</ Tuner -	Shift + << /
>>/ Tuner +	Shift + >> /
PR- / I << AUX2	Shift + I << / Preset-
PR+/ >>I AUX2	Shift + >>I / Preset+
Menu AUX2	Shift + Menu / Home

Original	Rechange
Up AUX2	Shift + Up
Left / RDS AUX2	Shift + Left
OK AUX2	Shift + OK
Right / PTY AUX2	Shift + Right
Clear AUX2	Shift + Exit / Cancel / Clear
Down AUX2	Shift + Down
Back/ St- Mono	Shift + Back / Return
PR+/ >>I AUX2	Shift + CH+ /
PR- / I << AUX2	Shift + CH- /
1 AUX2	Shift + 1
2 AUX2	Shift + 2
3 AUX2	Shift + 3
4 AUX2	Shift + 4
5 AUX2	Shift + 5
6 AUX2	Shift + 6
7 AUX2	Shift + 7
8 AUX2	Shift + 8

Original	Rechange	Original	Rechange
9 AUX2	SHIFT + BLUETOOTH 9 Shift + 9		
Guide AUX2	SHIFT + -/-- GUIDE EPG Shift + Guide / EPG / -/--		
0 AUX2	SHIFT + HDMI - SAT 0 Shift + 0		