Original		Rechange	
DISPLAY	Display	MEDIA DISPLAY	Display / Media
EJECT	Eject	SURROUND	Eject / Surround
ON/ STANDBY	On/ Standby		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
CH	CH+	CH PAGE +	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
CH	CH-	CH PAGE -	CH- / Page-
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
TRK	TRK Up	VOL +	Vol +
I.SELECT	I. Select	APP REPEAT	Green / APP / Repeat
0	0	HDMI - SAT 0	0

Original		Rechange	
COUNT.RST	Count. RST	NETFLIX SEARCH	Red / Netflix / Search
TRK	TRK Down	VOL -	Vol -
F.ADV	F. ADV	GOTO TEXT	Text / Goto
INDEX	Index	ANGLE INFO	Info / Angle
COUNT/TR	Count. TR	YouTube REPEAT A-B	Yellow / YouTube / Repeat
CLR/RST	CLR/ RST	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MENU	Menu	HOME MENU	Menu / Home
REC	Rec	REC MODE	Rec / Rec Mode
TIMER	Timer Rec	TIMER SLEEP	Sleep / Timer
PLAY	Play/ Up		Up
PLAY	Play/ Up	SLOW	Play / Slow
REW	<</ Left	TUNE-	<< / Tune-
REW	<</ Left		Left
FF	>>/ Right	TUNE+	>> / Tune+
FF	>>/ Right		Right
SLOW	I>/ Slow	SHIFT + SLOW	Shift + Play /
STOP	Stop/ Down		Down

Original	Rechange	Original	Rechange
Stop/ Down	Stop / Hold		
Pause/ Still / OK	OK		
Pause/ Still / OK	Pause / Step / Freeze		
SP/ LP	Setup / OPT /		
Audio	Audio / Lang I/II		
Tv/ Video	Smart / List		
A. Dub	Sound / Title		
SAT/ Moni.	D. Menu / Top		