Original	Rechange	Original	Rechange
Power	Power	0	0
Mute	Mute	-/--/EXIT	Guide
Up	Up	Exit	Exit
Down	Down	P<P/Swap	Pre Ch
Right	Right	Vol +	Vol +
Left	Left	Vol -	Vol -
OK/Select	Ok	P+	Ch +
M	Menu	P-	Ch -
1	1	PP	Eject
2	2	I-II	Dual
3	3	Tv/DTV	TV/R
4	4	[≡]	Text
5	5	[≡O]	Options
6	6	AV/Source	AV
7	7	[≡+] / [X]	Format
8	8	[≡X] / [■■]	3D
9	9	[.≡] / [■]	Subt

Original	Rechange	Original	Rechange
[≡♦]	Media		
[≡?]	Back		
[≡i]	Info		
Red/ [+] / Wide/ ↑	Red		
Green/ ↓	Green		
Yellow	Yellow		
Blue/ Guide	Blue		
[i]	D. Menu		