











	Original	Replacement		Original	Replacement
	 Power	 Power		 Right	 Right
 1	1	 1	1	 Vol+	 Vol +
 2	2	 2	2	 Left	 Left
 3	3	 3	3	 Vol-	 Vol -
 4	4	 4	4	 OK	 Ok
 5	5	 5	5	 TV	 TV/R
 6	6	 6	6	 Menu	 Menu
 7	7	 7	7	 ?	 Smart
 8	8	 8	8	 A	 Red
 9	9	 9	9	 B	 Green
 0	0	 0	0		 Shift + Up
 -/--	-/--	 -/--	GUIDE		 Shift + Down
 Mute	 MUTE	 MUTE	Mute		 Shift + Right
 P+	 Up	 Up	Up		 Shift + Left
 P+	 Ch +	 Ch +	Ch +		 Blue
 P-	 Down	 Down	Down		 Yellow
 P-	 Ch -	 Ch -	Ch -		 Sleep

	Original	Replacement		Original	Replacement
	 Power	 Power		 Right	 Right
 1	1	 1	1	 Vol+	 Vol +
 2	2	 2	2	 Left	 Left
 3	3	 3	3	 Vol-	 Vol -
 4	4	 4	4	 OK	 Ok
 5	5	 5	5	 TV	 TV/R
 6	6	 6	6	 Menu	 Menu
 7	7	 7	7	 ?	 Smart
 8	8	 8	8	 A	 Red
 9	9	 9	9	 B	 Green
 0	0	 0	0		 Shift + Up
 -/--	-/--	 -/--	GUIDE		 Shift + Down
 Mute	 MUTE	 MUTE	Mute		 Shift + Right
 P+	 Up	 Up	Up		 Shift + Left
 P+	 Ch +	 Ch +	Ch +		 Blue
 P-	 Down	 Down	Down		 Yellow
 P-	 Ch -	 Ch -	Ch -		 Sleep



