



Original	Replacement	Original	Replacement
 On/Standby	 Power	 Rec/Pause	 Rec
 Clock	 3D	 Repeat	 Text
 Sleep	 Sleep	 Memory	 Ok
 Timer	 AV	 Clear	 Exit
 CD	 Yellow	 Random	 TV/R
 Video/AUX	 Red	 Treble+	 Ch +
 Tuner(Band)	 Green	 Treble-	 Ch -
 Tape	 Blue	 Bass+	 Up
 Volume+	 Vol +	 Bass-	 Down
 Volume-	 Vol -		
 >>I/Presets Up	 >>I		
 I<</Presets	 I<<		
 <</Tun Down	 <<		
 Tun Up/>>	 >>		
 Play	 Play		
 Pause	 Pause		
 Stop	 Stop		

