







































































Original		Replacement		Original		Replacement	
	Power		Power		CH-		Ch -
	Mute		Mute		Up		Up
	1		1		Down		Down
	2		2		Right		Right
	3		3		Left		Left
	4		4		OK		Ok
	5		5		Vol+		Vol +
	6		6		Vol-		Vol -
	7		7		PG+		>>
	8		8		PG-		<<
	9		9		Audio		Dual
	0		0		Mode		Media
	Tv/R		TV/R		EPG		Guide
	Last		Back		Favor		Pre Ch
	Menu		Menu		Red		Red
	Exit		Exit		Green		Green
	CH+		Ch +		Yellow		Yellow





	Original	Replacement	
	Blue		Blue
	Info		Info
	Sleep		Sleep
	Sub-T		Subt
	Text		Text

	Original	Replacement

