

































































































Original		Replacement		Original		Replacement	
	Power		Power		Internet/PIP		Media
	HDMI/Control		Smart		1		1
	Rec		Rec		2		2
	Stop		Stop		3		3
	Play		Play		4		4
	Pause		Pause		5		5
	<<		<<		6		6
	>>		>>		7		7
	l<<		l<<		8		8
	>>l		>>l		9		9
	Red/Zoom/↑ ↓		Red		0		0
	Green/Repeat/↓		Green		Text		Text
	Yellow/Root		Yellow		Info		Info
	Blue/Title		Blue		Source		AV
	Screen		Format		OK		Ok
	Lang		Dual		Up		Up
	Subtitle		Subt		Down		Down





	Original	Replacement		Original	Replacement
					
	Right	Right			
					
	Left	Left			
					
	P+	Ch +			
					
	P-	Ch -			
					
	Vol+	Vol +			
					
	Vol-	Vol -			
					
	Menu	Menu			
					
	Mute	Mute			
					
	Return	Back			
					
	Swap	Pre Ch			
					
	FAV	Shift + Pre Ch			
					
	EPG	Guide			
					
	Sleep	Sleep			
					
	Search Mode	Shift + AV			
					
	Ball/Angle	Options			
					
	Display	Shift + Info			
					
	Presets	TV/R			

