







































































Original	Replacement	Original	Replacement
 Power	 Power	 Right	 Right
 [ + ]	 3D	 Left	 Left
 Input	 AV	 OK	 Ok
 [ ]	 Subt	 1	 1
 [ II ]	 Format	 2	 2
 Scene	 Smart	 3	 3
 Audio	 Dual	 4	 4
 Red	 Red	 5	 5
 Green	 Green	 6	 6
 Yellow	 Yellow	 7	 7
 Blue	 Blue	 8	 8
 [ i+ ] / [ ? ]	 Info	 9	 9
 Return	 Back	 0	 0
 Tools	 Options	 [ ≡ ]	 Text
 Menu	 Menu	 ♥	 Shift + Pre Ch
 Up	 Up	 Vol+	 Vol +
 Down	 Down	 Vol-	 Vol -





Original	Replacement	Original	Replacement
 Mute	 Mute		
 Prog+	 Ch +		
 Prog-	 Ch -		
 Recall	 Pre Ch		

