







































































Original	Replacement	Original	Replacement
 Power	 Power	 >> /Preset-	 >>
 1	 1	 Vol+	 Vol +
 2	 2	 Vol-	 Vol -
 3	 3	 Sound Field+	 Ch +
 4	 4	 Sound Field-	 Ch -
 5	 5	 Mute	 Mute
 6	 6	 Sleep	 Sleep
 7	 7	 AMP Menu	 Menu
 8	 8	 Return	 Back
 9	 9	 Options	 Options
 0/10	 0	 Display	 Info
 Play/D.Tuning	 Play	 Home	 Smart
 Pause	 Pause	 Up	 Up
 <</Tuning-	 <<	 OK	 Ok
 >>/Tuning+	 >>	 Down	 Down
 <</Preset-	 <<	 Right	 Right
 Stop/Mem	 Stop	 Left	 Left








































































Original	Replacement
Folder+	Shift + Ch +
Folder-	Shift + Ch -
Preview(HDMI)/iPhone CTRL	Media
Repeat/Top	Text
Shuffle/Pop Up	AV
BD	Red
DVD	Green
TV	TV/R
Game	Yellow
Pure Direct	Pre Ch
Power Tv	Shift + Power
Input Tv	Shift + AV
1 TV	Shift + 1
2 TV	Shift + 2
3 TV	Shift + 3
4 TV	Shift + 4
5 TV	Shift + 5

Original	Replacement
6 TV	Shift + 6
7 TV	Shift + 7
8 TV	Shift + 8
9 TV	Shift + 9
0/10 TV	Shift + 0
Display TV	Shift + Info
Up TV	Shift + Up
OK TV	Shift + Ok
Down TV	Shift + Down
Right TV	Shift + Right
Left TV	Shift + Left
Return TV	Shift + Back
SA-CD/CD	Shift + Green
Options TV	Shift + Options
USB	Shift + Blue
Home TV	Shift + Smart
Play/D.Tuning TV	Shift + Play





Original	Replacement	Original	Replacement
 Power	 Power	 0/10 DVD	 0
 DVD	 Green	 Display DVD	 Info
 BD	 Red	 Up DVD	 Up
 SA-CD/CD	 Yellow	 Down DVD	 Down
 Video	 Blue	 Right DVD	 Right
 TV	 TV/R	 Left DVD	 Left
 Repeat/Top Menu	 Text	 OK DVD	 Ok
 Shuffle/Pop Up	 AV	 Return DVD	 Back
 1 DVD	 1	 Options DVD	 Options
 2 DVD	 2	 Home DVD	 Smart
 3 DVD	 3	 Play/D.Tuning	 Play
 4 DVD	 4	 <</Tuning-	 <<
 5 DVD	 5	 >>/Tuning+	 >>
 6 DVD	 6	 I<</Preset-	 I<<
 7 DVD	 7	 Pause DVD	 Pause
 8 DVD	 8	 Stop/Mem DVD	 Stop
 9 DVD	 9	 >>I/Preset+	 >>I



DVD




















































Original	Replacement
Repeat/Top Menu	Shift + Text
Shuffle/Pop Up Menu BD	Shift + AV
1 BD	Shift + 1
2 BD	Shift + 2
3 BD	Shift + 3
4 BD	Shift + 4
5 BD	Shift + 5
6 BD	Shift + 6
7 BD	Shift + 7
8 BD	Shift + 8
9 BD	Shift + 9
0/10 BD	Shift + 0
Display BD	Shift + Info
Return BD	Shift + Back
Options BD	Shift + Options
Up BD	Shift + Up
OK BD	Shift + Ok

Original	Replacement
Down BD	Shift + Down
Right BD	Shift + Right
Left BD	Shift + Left
Home BD	Shift + Smart
Play/D.Tuning BD	Format
Pause BD	3D
Stop/Mem BD	Subt
<</Tuning- BD	Shift + Format
>>/Tuning+ BD	Shift + 3D
I<</Preset- BD	Ch -
>>/Tuning+ BD	Ch +
Vol+	Vol +
Vol-	Vol -
Mute	Mute





Original		Replacement		Original		Replacement	
	Power		Power		8		8
	Vol+		Vol +		9		9
	Vol-		Vol -		0/10		0
	Mute		Mute		Display		Info
	SA-CD/CD		Red		Play/D.Tuning		Play
	BD		Green		<</Tuning-		<<
	Video		Yellow		>>/Tuning+		>>
	DVD		Blue		Pause		Pause
	Repeat/Top		Text		Stop/Mem		Stop
	Shuffle/Pop Up		AV		I<</Preset-		I<<
	1		1		>>I/Preset+		>>I
	2		2				
	3		3				
	4		4				
	5		5				
	6		6				
	7		7				





Original	Replacement
 Power	 Power
 BD	 Green
 DVD	 Blue
 Video	 Yellow
 SA-CD/CD	 Red
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/10	 0
 Display	 Info
 Up	 Up

Original	Replacement
 OK	 Ok
 Down	 Down
 Right	 Right
 Left	 Left
 Home	 Smart
 Play/D.Tuning	 Play
 <</Tuning-	 <<
 >>/Tuning+	 >>
 I<</Preset-	 I<<
 Pause	 Pause
 Stop/Mem	 Stop
 >>I/Preset+	 >>I
 Mute	 Mute
 Vol+	 Vol +
 Vol-	 Vol -

