





































































































Original	Replacement	Original	Replacement
 Power	 Power	 Aspect	 Format
 Text / Display	 Text	 Exit	 Exit
 Call / Index	 Info	 Up / P+	 Up
 1	 1	 Up / P+	 Ch +
 2	 2	 Down / P-	 Down
 3	 3	 Down / P-	 Ch -
 4	 4	 Right / Vol +	 Right
 5	 5	 Right / Vol +	 Vol +
 6	 6	 Left / Vol -	 Left
 7	 7	 Left / Vol -	 Vol -
 8	 8	 OK	 Ok
 9	 9	 Red	 Red
 0	 0	 Green	 Green
 Recall	 Pre Ch	 Yellow	 Yellow
 Input	 AV	 Blue	 Blue
 Menu / DVD	 Menu	 I/II	 Dual
 →  [ ]  ←	 3D	 Audio	 Shift + Dual







Original	Replacement	Original	Replacement
 Power	 Power		
 Menu DVD	 Menu		
 Up	 Up		
 Down	 Down		
 Right	 Right		
 Left	 Left		
 OK	 Ok		
 Pause	 Pause		
 Play	 Play		
 <<	 <<		
 >>	 >>		
 Open/Close	 Eject		
 Stop	 Stop		
 I<<	 I<<		
 >>I	 >>I		





