






















































Original	Replacement	Original	Replacement
 Power	 Power	 Fav	 Shift + Pre Ch
 Mute	 Mute	 Size	 Eject
 1	 1	 Vol+	 Vol +
 2	 2	 Vol-	 Vol -
 3	 3	 CH+ / Page+	 Ch +
 4	 4	 CH- / Page-	 Ch -
 5	 5	 QV Top	 Smart
 6	 6	 Source	 AV
 7	 7	 Menu	 Menu
 8	 8	 Q.Menu	 D. Menu
 9	 9	 Display	 Info
 0	 0	 Up	 Up
 Audio Lang. I/II	 Dual	 Left	 Left
 Subtl	 Subt	 OK	 Ok
 EPG	 Guide	 Right	 Right
 → P ←	 Format	 Down	 Down
 → S ←	 Shift + Dual	 Exit	 Exit





Original		Replacement		Original		Replacement	
	Red		Red		CEC / F.Fwd		Media
	FAV CH		Pre Ch				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Text / Play/Pause		Text				
	Text / Play/Pause		Play				
	Text / Play/Pause		Pause				
	Index / Repeat		Shift + Text				
	Index / Repeat		Shift + Info				
	Cancel / Time		Back				
	Cancel / Time		Shift + AV				
	Hold / Stop		Stop				
	Mix / Prev		I<<				
	Subpg / Next		>>I				
	Reveal / F.Rev		<<				
	CEC / F.Fwd		>>				

