







































































Original	Replacement	Original	Replacement
 Standby	 Power	 TV/Radio	 TV/R
 Source	 AV	 Display	 Info
 1	 1	 Up	 Up
 2	 2	 Left	 Left
 3	 3	 OK	 Ok
 4	 4	 Right	 Right
 5	 5	 Down	 Down
 6	 6	 Menu	 Menu
 7	 7	 Exit	 Exit
 8	 8	 Mute	 Mute
 9	 9	 EPG	 Guide
 0	 0	 Home	 Smart
 Fav	 Pre Ch	 Vol+	 Vol +
 Recall	 Back	 Vol-	 Vol -
 P.Mode	 Shift + Format	 CH+	 Ch +
 S.Mode	 Shift + Dual	 CH--	 Ch -
 Sleep	 Sleep	 Rec	 Rec





Original	Replacement		
T.SHIFT	T.Shift	APP MEDIA	Media
AUDIO	Audio	SOUND DUAL	Dual
ASPECT SIZE	Size / Aspect	PICTURE FORMAT	Format
TEXT	Text	REPEAT TEXT	Text
HOLD	Hold	SHIFT + [Stop]	Shift + Stop
REVEAL	Reveal	SHIFT + [Pause]	Shift + Pause
MOUSE	Mouse	SETTINGS OPT	Options
[Play/Pause]	Play / Pause	PLAY MODE [Play]	Play
[Play/Pause]	Play / Pause	[Pause]	Pause
[Stop]	Stop	[Stop]	Stop
SUBTITLE	Subtitle	AD SUBT	Subt
RECLIST INDEX	Index / Reclist	DISC NAV LIST	List
[Left Arrow]	<<	[Left Arrow]	<<
[Right Arrow]	>>	[Right Arrow]	>>
SUBPAGE	I<< / Subpage	[Left Arrow]	I<<
MIX	>>I / Mix	[Right Arrow]	>>I
[Red]	Red	A	Red

Original	Replacement		
[Green]	Green	B	Green
[Yellow]	Yellow	C	Yellow
[Blue]	Blue	D	Blue

