





































Original	Recharge	Original	Recharge
 Power STB	 Power	 Left	 Left
 <<	 <<	 OK	 Ok
 Play	 Play	 Right	 Right
 Pause	 Pause	 Down	 Down
 >>	 >>	 Back	 Back
 <	 <<	 Guide	 Guide
 >	 >>	 X	 Exit
 Stop	 Stop	 Vol+	 Vol +
 Rec	 Rec	 Vol-	 Vol -
 Red	 Red	 ↑	 Shift + Up
 Green	 Green	 ↓	 Shift + Down
 Yellow	 Yellow	 CH+	 Ch +
 Blue	 Blue	 CH-	 Ch -
 Video	 Format	 Mute	 Mute
 Menu	 Menu	 P < P	 Pre Ch
 i	 Info	 1	 1
 Up	 Up	 2	 2





Original	Recharge	Original	Recharge
PWR On/Off		Power	
Epg		Guide	
Subt.List		Subt	
Opt?		Options	
App		Media	
Sleep Timer		Sleep	
TV		TV/R	
Text		Text	
Zoom		Eject	
Menu		Menu	
Menu Up		Up	
Menu Left		Left	
OK Enter		Ok	
Menu Right		Right	
Menu Down		Down	
Back		Back	
CH/Page+		Ch +	
		Audio	 Dual
		CH/Page-	 Ch -
		1. ?	 1
		2abc	 2
		3def	 3
		4ghi	 4
		5jkl	 5
		6mno	 6
		7pqrm	 7
		8tuv	 8
		9wxyz	 9
		0/10	 0
		FAV Pref.	 Pre Ch
		Red	 Red
		Green	 Green
		Yellow	 Yellow
		Blue	 Blue







































Original	Recharge	Original	Recharge
Freeze		Stop	
H/V Play		Play	
East		>>I	
Lang./Rewind		<<	
LNB F.Forward		>>	
Dec/Pause		Pause	





Original	Recharge	Original	Recharge
PWR On/Off	 Power	CH/Page+	 Ch +
Mute	 Mute	Volume-	 Vol -
Opt?	 Options	Audio	 Dual
App	 Media	CH/Page-	 Ch -
Subt.List	 Subt	1. ?	 1
Info	 Info	2abc	 2
Video	 D. Menu	3def	 3
Zoom	 Eject	4ghi	 4
Menu	 Menu	5jkl	 5
Menu Up	 Up	6mno	 6
Menu Left	 Left	7pqrm	 7
OK Enter	 Ok	8tuv	 8
Menu Right	 Right	9wxyz	 9
Exit	 Exit	Guide Pilote	 Guide
Menu Down	 Down	0/10	 0
Back	 Back	FAV Pref.	 Pre Ch
Volume+	 Vol +	Red	 Red





Original	Recharge	Original	Recharge
Green	 B	Green	
Yellow	 C	Yellow	
Blue	 D	Blue	
Dev	 LIST	List	
West	 I<<	I<<	
Dec/Pause	 II	Pause	
	 Shift + Ch +		
	 Shift + Ch -		
Freeze	 ■	Stop	
East	 >>I	>>I	
LNB F.Forward	 >>	>>	
Lang./Rewind	 <<	<<	
H/V Play	 ▶	Play	

