






































	Original	Rechange		Original	Rechange
	Tv/Video		TV/Radio /		
	Power		Power		
	1		1		
	2		2		
	3		3		
	4		4		
	5		5		
	6		6		
	7		7		
	8		8		
	9		9		
	-/--		Guide / EPG / -/--		
	10/0		0		
	Enter		OK		
	Vol+		Vol+		
	Vol-		Vol-		
	CH-		CH- / Page-		

	Original	Rechange	
	CH+		CH+ / Page+





Original	Recharge
 Sleep	 Sleep / Timer
 Timer Menu	 Shift + Sleep / Timer
 Theatre Sync	 Red / Netflix / Search
 Power	 Power
 Display	 Display / Media
 Time/Text	 Text / Goto
 Dimmer	 Mute / Dimmer
 Function+	 CH+ / Page+
 Key Control b	 Smart / List
 Key Control #	 Shift + Smart / List
 Score	 Setup / OPT /
 Function-	 CH- / Page-
 Karaoke Mode	 Sound / Title
 Karaoke Pon	 Yellow / YouTube / Repeat
 Repeat/FM	 Green / APP / Repeat
 Picture Navi	 Picture / Format
 1	 1

Original	Recharge
 2	 2
 3	 3
 Audio	 Audio / Lang I/II
 4	 4
 5	 5
 6	 6
 Subtitle	 Subtitle / EQ
 7	 7
 8	 8
 9	 9
 Angle	 Info / Angle
 Clear	 Exit / Cancel / Clear
 0	 0
 Folder-	 Shift + CH- /
 Folder+	 Shift + CH+ /
 DVD Top Menu	 D.Menu / Top
 DVD/USB/Tuner	 Menu / Home





Original	Recharge
EQ	Shift + Subtitle / EQ
Up	Up
Left	Left
Enter	OK
Right	Right
Volume+	Vol+
Down	Down
Display/[ *]	Shift + Display / Media
Volume-	Vol-
Return	Back / Return
I<</Preset-	I<< / Preset-
←/Replay/<I Step	Shift + Left
→/Advance/Step II>	Shift + Right
>>I/Preset+	>>I / Preset+
<</Tuning -/<I	<< / Tune-
Play	Play / Slow
>>/Tuning	>> / Tune+

Original	Recharge
Pause	Pause / Step / Freeze
Stop	Stop / Hold



+/Slow I>