


































**Originalfernbedienung    Ersatzfernbedienung**

|   |           |   |                            |
|---|-----------|---|----------------------------|
|    | Power     |    | Power                      |
|    | Mute      |    | Mute / Dimmer              |
|    | 1         |    | 1                          |
|    | 2         |    | 2                          |
|    | 3         |    | 3                          |
|    | 4         |    | 4                          |
|    | 5         |    | 5                          |
|    | 6         |    | 6                          |
|    | 7         |    | 7                          |
|    | 8         |    | 8                          |
|   | 9         |   | 9                          |
|  | AV/Source |  | AV / Input / RDS           |
|  | 0         |  | 0                          |
|  | Exit      |  | Exit / Cancel / Clear      |
|  | -/--      |  | Shift + Guide / EPG / -/-- |
|  | CH+       |  | CH+ / Page+                |
|  | [i]/Info  |  | Info / Angle               |

**Originalfernbedienung    Ersatzfernbedienung**

|   |           |   |                             |
|---|-----------|---|-----------------------------|
|    | Vol+      |    | Vol+                        |
|    | CH-       |    | CH- / Page-                 |
|    | I-II      |    | Audio / Lang I/II           |
|    | Vol-      |    | Vol-                        |
|    | Up        |    | Up                          |
|    | Left      |    | Left                        |
|    | OK/Select |    | OK                          |
|    | Right     |    | Right                       |
|    | Menu      |    | Menu / Home                 |
|    | Down      |    | Down                        |
|   | TV/DTV    |   | TV/Radio /                  |
|  | Red       |  | Red / Netflix / Search      |
|  | Green     |  | Green / APP / Repeat        |
|  | Yellow    |  | Yellow / YouTube / Repeat   |
|  | Blue      |  | Blue / Prime Video / Random |
|  | [≡]/Text  |  | Text / Goto                 |
|  | [≡o]      |  | Sleep / Timer               |





| Originalfernbedienung | Ersatzfernbedienung | Originalfernbedienung | Ersatzfernbedienung |
|-----------------------|---------------------|-----------------------|---------------------|
|                       | [≡+]/[X]            |                       | << / Tune-          |
|                       | [≡x]/[··]           |                       | >> / Tune+          |
|                       | [.]/[*]             |                       | I<< / Preset-       |
|                       | [≡♦]/[+]/Wide       |                       | Picture / Format    |
|                       | [≡?]                |                       | >>I / Preset+       |
|                       | [≡i]/Guide          |                       | Guide / EPG / -/--  |
|                       | P<P/SWAP            |                       | Fav / Marker / PC   |
|                       | PP                  |                       | Back / Return       |
|                       |                     |                       |                     |
|                       |                     |                       |                     |
|                       |                     |                       |                     |
|                       |                     |                       |                     |
|                       |                     |                       |                     |
|                       |                     |                       |                     |
|                       |                     |                       |                     |
|                       |                     |                       |                     |
|                       |                     |                       |                     |
|                       |                     |                       |                     |
|                       |                     |                       |                     |
|                       |                     |                       |                     |

