







































































Originalfernbedienung Ersatzfernbedienung

|   |         |   |               |
|---|---------|---|---------------|
|    | On      |    | Shift + Power |
|    | Standby |    | Power         |
|    | Sleep   |    | Sleep         |
|    | Dimmer  |    | Smart         |
|    | Status  |    | Options       |
|    | Search  |    | TV/R          |
|    | BD      |    | 1             |
|    | Tuner   |    | 2             |
|    | Band    |    | 3             |
|    | DVD     |    | 4             |
|   | Dock    |   | 5             |
|  | Shift   |  | 6             |
|  | TV      |  | 7             |
|  | Game    |  | 8             |
|  | SAT/CBL |  | 9             |
|  | V.AUX   |  | 0             |
|  | Memory  |  | Subt          |



Originalfernbedienung Ersatzfernbedienung

|   |                |   |              |
|---|----------------|---|--------------|
|    | Mode           |    | Format       |
|    | CH+            |    | Ch +         |
|    | CH-            |    | Ch -         |
|    | Tuning Up      |    | Shift + Ch + |
|    | Tuning Down    |    | Shift + Ch - |
|    | Quick Select 1 |    | Shift + 1    |
|    | Quick Select 2 |    | Shift + 2    |
|    | Quick Select 3 |    | Shift + 3    |
|    | Quick Select 4 |    | Shift + 4    |
|    | Menu           |    | Menu         |
|   | Audio Adjust   |   | Dual         |
|  | Vol+           |  | Vol +        |
|  | Vol-           |  | Vol -        |
|  | Up             |  | Up           |
|  | Down           |  | Down         |
|  | Right          |  | Right        |
|  | Left           |  | Left         |









Originalfernbedienung Ersatzfernbedienung

|   |                 |   |               |
|---|-----------------|---|---------------|
|    | Enter           |    | Ok            |
|    | CH Level        |    | Media         |
|    | Return          |    | Back          |
|    | Night           |    | 3D            |
|    | Restorer        |    | Exit          |
|    | Tone            |    | List          |
|    | Mute            |    | Mute          |
|    | Surround Left   |    | Shift + Left  |
|    | Surround Right  |    | Shift + Right |
|   | Audio Delay -   |   | Shift + Vol - |
|  | Audio Delay +   |  | Shift + Vol + |
|  | I<< Ipod        |  | I<<           |
|  | Stop Ipod       |  | Stop          |
|  | Play/Pause Ipod |  | Play          |
|  | >>I Ipod        |  | >>I           |
|  | << Ipod         |  | <<            |
|  | >> Ipod         |  | >>            |

Originalfernbedienung Ersatzfernbedienung

|   |             |   |      |
|---|-------------|---|------|
|  | Repeat Ipod |  | Text |
|  | Random Ipod |  | Info |
|   |             |   |      |
|   |             |   |      |
|   |             |   |      |
|   |             |   |      |
|   |             |   |      |
|   |             |   |      |
|   |             |   |      |
|   |             |   |      |
|   |             |   |      |
|   |             |   |      |
|   |             |   |      |
|   |             |   |      |
|   |             |   |      |

